


# HONDA ENGINES

## OWNER'S MANUAL GXV160K1



**WARNING:**

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

31ZE7610  
00X31-ZE7-6100


1

©1994 American Honda Motor Co., Inc.  
All Rights Reserved

### SAFETY INFORMATION

- Understand the operation of all controls and learn how to stop the engine quickly in case of emergency. Make sure the operator receives adequate instruction before operating the equipment.
- Your engine's exhaust contains poisonous carbon monoxide. Do not run the engine without adequate ventilation, and never run the engine indoors.
- The engine and exhaust become very hot during operation. Keep the engine at least 1 meter (3 feet) away from buildings and other equipment during operation. Keep flammable materials away, and do not place anything on the engine while it is running.

### COMPONENT IDENTIFICATION AND SAFETY LABEL LOCATION



5

### CONTENTS

Refer to the page for detailed information.


1. INTRODUCTION _____ 3	Engine Oil . . . . . 17
Serial number location . . . . . 3	Recommended Oil . . . . . 17
2. SAFETY MESSAGES _____ 4	Oil Level Check . . . . . 17
Damage Prevention Messages . . . . . 4	Oil Change . . . . . 18
Safety Information . . . . . 5	Air Cleaner . . . . . 19
Safety Label Location . . . . . 5	Inspection . . . . . 19
Component Identification . . . . . 5	Cleaning . . . . . 20
3. THROTTLE CABLE CONNECTION _____ 6	Spark Plug . . . . . 21
4. FLYWHEEL BRAKE _____ 7	Idle Speed Adjustment . . . . . 22
Operation Inspection . . . . . 7	Spark Arrester . . . . . 23
5. BEFORE OPERATION CHECKS _____ 7	Removal . . . . . 23
6. OPERATION _____ 8	Cleaning and Inspection . . . . . 23
Starting The Engine . . . . . 8	8. TRANSPORTING _____ 24
Operating The Engine . . . . . 8	9. STORAGE _____ 24
High Altitude Operation . . . . . 9	Preparation . . . . . 24
Stopping The Engine . . . . . 9	Cleaning . . . . . 24
7. MAINTENANCE _____ 10	Fuel . . . . . 25
Maintenance Importance . . . . . 10	Draining . . . . . 26
Maintenance Safety . . . . . 11	Engine Oil . . . . . 27
Safety Precautions . . . . . 11	Storage . . . . . 27
Emission Control System . . . . . 12	Removal From Storage . . . . . 28
Maintenance Schedule . . . . . 14	10. TROUBLESHOOTING _____ 29
Fuel . . . . . 15	11. SPECIFICATIONS _____ 30
Adding Fuel . . . . . 15	General . . . . . 30
Oxygenated Fuels . . . . . 16	Tuneup . . . . . 30
	12. WARRANTY SERVICE INFORMATION _____ 31

2


### 3. THROTTLE CABLE CONNECTION

The throttle lever is provided with holes for attaching the throttle cable.

- Remove the screw and the cable holder.
- Hook the solid wire cable end into the throttle lever as shown.
- Move the throttle cable control into the fast (or high) throttle position.
- Move the throttle lever by pulling the throttle cable until the throttle lever just contacts the choke arm. Install the cable holder securing the throttle cable and tighten it securely.



- Move the throttle control to the choke position and verify that the engine choke rod moves the carburetor choke arm fully closed. If necessary, adjust screw B so it just contacts the choke travel stop.



- Start the engine and move the throttle lever to the fast (or high) position. Using a tachometer, check the engine speed. Turn screw A to obtain the top no load engine speed specified by the equipment manufacturer.
- N1 types: Move the throttle cable control lever to the stop position and confirm that the engine shuts off.

6


## 1. INTRODUCTION

Thank you for purchasing a Honda engine. We want to help you to get the best results from your new engine and to operate it safely. This manual contains information on how to do that; please read it carefully before operating the engine. If a problem should arise, or if you have any questions about your engine, consult an authorized Honda servicing dealer.

All information in this publication is based on the latest product information available at the time of printing. Illustrations are based on the GXV160K1A12 model. American Honda Motor Co., Inc. reserves the right to make changes at any time without notice and without incurring any obligation. No part of this publication may be reproduced without written permission.

This manual should be considered a permanent part of the engine and should remain with the engine if resold.

Record the engine model identification code and serial number in the space below. You will need this information when ordering parts and when making technical or warranty inquiries. This information is located on the crankcase, below the fuel tank.



ZG9EAAA.CDR


Serial number: **GJ03** - \_\_\_\_\_

3

## 4. FLYWHEEL BRAKE (A12 models only)

### Flywheel Brake Operation Inspection


1. Release the flywheel brake lever (located on equipment), and verify that there is a strong resistance when pulling on the recoil starter. Also verify that the governor arm is moved to the idle (slow), position and there is freeplay in the cable. The cable should deflect 10 - 15 mm from centerline as shown when the cable is new.



ZG9EACAA.CDR

2. Move the flywheel brake lever to release the flywheel brake, and verify that there is clearance between the governor arm and the throttle return rod when the throttle is in the fast (or high) position.

Also verify that there is at least 2 mm clearance between the stopper and the brake cable bracket.



ZG9EACAB.CDR

## 5. BEFORE OPERATION CHECKS

Always check the following items before you start the engine:

1. Fuel level (see page 15).
2. Oil level (see page 17).
3. Air cleaner (see page 19).
4. General inspection: Check for fluid leaks and loose or damaged parts.

7

## 2. SAFETY MESSAGES

Your safety and the safety of others is very important. We have provided important safety messages in this manual and on the engine. Please read these messages carefully.

A safety message alerts you to potential hazards that could hurt you or others. Each safety message is preceded by a safety alert symbol **▲** and one of three words: DANGER, WARNING, or CAUTION.

These words mean:

**▲ DANGER**

You **WILL** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

**▲ WARNING**

You **CAN** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

**▲ CAUTION**

You **CAN** be **HURT** if you don't follow instructions.

Each message tells you what the hazard is, what can happen, and what you can do to avoid or reduce injury.

### DAMAGE PREVENTION MESSAGES

You will also see other important messages that are preceded by the word **NOTICE**.

This word means:

**NOTICE**

Your engine or other property can be damaged if you don't follow instructions.


The purpose of these messages is to help prevent damage to your engine, other property, or the environment.

4

## 6. OPERATION

### STARTING THE ENGINE

1. Turn the fuel valve to the ON position.



ZG9FAAAA.CDR

2. **FOR STARTING A COLD ENGINE:** Move the throttle control to the choke position.
3. **FOR RESTARTING A WARM ENGINE:** Do not use the choke when the engine is warm. Move the throttle control slightly past the idle position.
4. **FLYWHEEL BRAKE MODELS:** Move the flywheel brake lever (located on equipment) to release the flywheel brake.
5. Pull the starter grip lightly until resistance is felt, then pull briskly.

**NOTICE**

Do not allow the starter grip to snap back against the engine. Return it gently to prevent damage to the starter.

6. If the choke was used to start the engine, move the throttle to the fast (or high) position as soon as the engine warms up enough to run smoothly without use of the choke.
7. **FLYWHEEL BRAKE MODELS:** Continue to hold the flywheel brake lever (located on equipment). The engine will stop if you release the flywheel brake lever.

### OPERATING THE ENGINE

1. Position the throttle control for the desired engine speed. For best engine performance, it is recommended that the engine be operated with the throttle in the fast (or high) position.

8

## HIGH ALTITUDE OPERATION

At high altitude, the standard carburetor air-fuel mixture will be too rich. Performance will decrease, and fuel consumption will increase. A very rich mixture will also foul the spark plug and cause hard starting.

High altitude performance can be improved by specific modifications to the carburetor. If you always operate your engine at altitudes above 1,800 meters (6,000 feet) have an authorized Honda servicing dealer perform this carburetor modification.


Even with carburetor modification, engine horsepower will decrease about 3.5% for each 300 meter (1,000 foot) increase in altitude. The effect of altitude on horsepower will be greater than this if no carburetor modification is made.

### Notice

When the carburetor has been modified for high altitude operation, the air-fuel mixture will be too lean for low altitude use. Operation at altitudes below 1,800 meters (6,000 feet) with a modified carburetor may cause the engine to overheat and result in serious engine damage. For use at low altitudes, have an authorized Honda servicing dealer return the carburetor to original factory specifications. At high altitude, the standard carburetor air-fuel mixture will be too rich. Performance will decrease, and fuel consumption will increase. A very rich mixture will also foul the spark plug and cause hard starting.

## STOPPING THE ENGINE

1. Move the throttle control to the slow position.
2. Move the throttle control to the stop position.  
FLYWHEEL BRAKE MODELS:  
Release the flywheel brake lever (located on equipment) to stop the engine.
3. Turn the fuel valve to the OFF position if you do not intend to restart the engine soon.



9

## Problems That May Affect Emissions

If you are aware of any of the following symptoms, have your engine inspected and repaired by your servicing dealer.

- Hard starting or stalling after starting.
- Rough idle.
- Misfiring or backfiring under load.
- Afterburning (backfiring).
- Black exhaust smoke or high fuel consumption.

## Replacement Parts

The emission control systems on your Honda engine were designed, built, and certified to conform with EPA and California emission regulations. We recommend the use of genuine Honda parts whenever you have maintenance done. These original-design replacement parts are manufactured to the same standards as the original parts, so you can be confident of their performance. The use of replacement parts that are not of the original design and quality may impair the effectiveness of your emission control system.

A manufacturer of an aftermarket part assumes the responsibility that the part will not adversely affect emission performance. The manufacturer or rebuilder of the part must certify that use of the part will not result in a failure of the engine to comply with emission regulations.

## Maintenance

Follow the maintenance schedule on page 14. Remember that this schedule is based on the assumption that your machine will be used for its designed purpose. Sustained high-load or high-temperature operation, or use in unusually wet or dusty conditions, will require more frequent service.

13

## 7. MAINTENANCE

### THE IMPORTANCE OF MAINTENANCE

Good maintenance is essential for safe, economical and trouble-free operation. It will also help reduce pollution.

### WARNING

Improper maintenance, or failure to correct a problem before operation, can cause a malfunction in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

To help you properly care for your engine, the following pages include a maintenance schedule, routine inspection procedures, and simple maintenance procedures using basic hand tools. Other service tasks that are more difficult, or require special tools, are best handled by professionals and are normally performed by a Honda technician or other qualified mechanic.

The maintenance schedule applies to normal operating conditions. If you operate your engine under severe conditions, such as sustained high-load or high-temperature operation, or use in unusually wet or dusty conditions, consult your servicing dealer for recommendations applicable to your individual needs and use.

**Maintenance, replacement, or repair of the emission control devices and systems may be performed by any engine repair establishment or individual, using parts that are "certified" to EPA standards.**

10

## MAINTENANCE SCHEDULE

ITEM	REGULAR SERVICE PERIOD (3) Perform at every indicated month or operating hour interval, whichever comes first.	Each use	First month or 20 hrs.	Every 3 months or 50 Hrs.	Every 6 months or 100 Hrs.	Every year or 300 Hrs.	Refer to page
• Engine oil	Check level	O					17
	Change		O		O		18
• Air cleaner	Check	O					19
	Clean-Replace*			O (1)			20
Flywheel brake operation	Check			O			7
Flywheel brake pad	Check-Adjust		O (2)		O (2)		-
• Spark plug	Clean-Adjust				O		21
	Replace					O	21
Spark arrester (optional part)	Clean				O		23
• Idle Speed	Check-Adjust					O(2)	22
• Valve Clearance	Check-Adjust					O(2)	-
• Fuel tank and filter	Clean					O(2)	-
• Fuel line	Check						Every 2 years (2)(Replace if necessary)

- Emission related items.

\* Replace the paper element only.

- (1) Service more frequently when used in dusty areas.
- (2) These items should be serviced by an authorized Honda servicing dealer, unless the owner has the proper tools and is mechanically proficient. Refer to the Honda shop manual for service procedures.
- (3) For commercial use, log hours of operation to determine proper maintenance intervals.

14

## MAINTENANCE SAFETY

Some of the most important safety precautions follow. However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

### WARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.

Always follow the procedures and precautions in this owner's manual.

## SAFETY PRECAUTIONS

- Make sure the engine is off before you begin any maintenance or repairs. This will eliminate several potential hazards:
  - **Carbon monoxide poisoning from engine exhaust.**  
Be sure there is adequate ventilation whenever you operate the engine.
  - **Burns from hot parts.**  
Let the engine and exhaust system cool before touching.
  - **Injury from moving parts.**  
Do not run the engine unless instructed to do so.
- Read the instructions before you begin, and make sure you have the tools and skills required.
- To reduce the possibility of fire or explosion, be careful when working around gasoline. Use only a nonflammable solvent, not gasoline, to clean parts. Keep cigarettes, sparks and flames away from all fuel related parts.

Remember that an authorized Honda servicing dealer knows your engine best and is fully equipped to maintain and repair it.

To ensure the best quality and reliability, use only new genuine Honda parts or their equivalents for repair and replacement.

11

## FUEL

Use unleaded gasoline with a pump octane rating of 86 or higher. This engine is certified to operate on unleaded gasoline. Unleaded gasoline produces fewer engine and spark plug deposits and extends exhaust system life.

### WARNING

Gasoline is highly flammable and explosive, and you can be burned or seriously injured when refueling.

- Stop engine and keep heat, sparks, and flame away.
- Refuel only outdoors.
- Wipe up spills immediately.

### NOTICE


Fuel can damage paint and some types of plastic. Be careful not to spill fuel when filling your fuel tank. Damage caused by spilling fuel is not covered under warranty.

Never use stale or contaminated gasoline or oil/gasoline mixture. Avoid getting dirt or water in the fuel tank.

## Adding Fuel

1. Remove the fuel tank cap.
2. Add fuel to the bottom of the fuel level limit in the neck of the fuel tank. Do not overfill. Wipe up spilled fuel before starting the engine.

**Fuel tank capacity:**  
2.0 / (0.53 US gal)



ZET/FABAA.CDR

15

## Emission Control System Information

### Source of Emissions

The combustion process produces carbon monoxide, oxides of nitrogen, and hydrocarbons. Control of hydrocarbons and oxides of nitrogen is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Honda utilizes lean carburetor settings and other systems to reduce the emissions of carbon monoxide, oxides of nitrogen, and hydrocarbons.

### The U.S. and California Clean Air Acts

EPA and California regulations require all manufacturers to furnish written instructions describing the operation, and maintenance of emission control systems.

The following instructions and procedures must be followed in order to keep the emissions from your Honda engine within the emission standards.

### Tampering and Altering

Tampering with or altering the emission control system may increase emissions beyond the legal limit. Among those acts that constitute tampering are:

- Removal or alteration of any part of the intake, fuel, or exhaust systems.
- Altering or defeating the governor linkage or speed-adjusting mechanism to cause the engine to operate outside its design parameters.

12

## Oxygenated Fuels

Some conventional gasolines are being blended with alcohol or an ether compound. These gasolines are collectively referred to as oxygenated fuels. To meet clean air standards, some areas of the United States and Canada use oxygenated fuels to help reduce emissions.

If you use oxygenated fuel, be sure it is unleaded and meets the minimum octane rating requirements.

Before using an oxygenated fuel, try to confirm the fuel's contents. Some states/provinces require this information to be posted on the pump.

The following are the EPA approved percentages of oxygenates:

- ETHANOL** — (ethyl or grain alcohol) 10% by volume  
You may use gasoline containing up to 10% ethanol by volume. Gasoline containing ethanol may be marketed under the name "Gasohol".
- MTBE** — (methyl tertiary butyl ether) 15% by volume  
You may use gasoline containing up to 15% MTBE by volume.
- METHANOL** — (methyl or wood alcohol) 5% by volume  
You may use gasoline containing up to 5% methanol by volume as long as it also contains cosolvents and corrosion inhibitors to protect the fuel system. Gasoline containing more than 5% methanol by volume may cause starting and/or performance problems. It may also damage metal, rubber, and plastic parts of your fuel system.

If you notice any undesirable operating symptoms, try another service station or switch to another brand of gasoline.

Fuel system damage or performance problems resulting from the use of an oxygenated fuel containing more than the percentages of oxygenates mentioned above are not covered under warranty.


16

## ENGINE OIL

### Recommended Oil

Use 4-stroke motor oil that meets or exceeds the requirements for API service classification SF, SG, or equivalent. Always check the API SERVICE label on the oil container to be sure it includes the letters SF, SG, or equivalent.

SAE 10W-30 is recommended for general use. Other viscosities shown in the chart may be used when the average temperature in your area is within the indicated range.




LM-AAJAA.CDR

### Oil Level Check

1. Check the oil with the engine stopped and level.
2. Remove the oil filler cap/dipstick and wipe it clean.
3. Insert the oil filler cap/dipstick into the oil filler neck as shown, but do not screw it in, then remove it to check the oil level.

OIL FILLER CAP/DIPSTICK




ZETFEAAA.CDR

4. If the oil level is near or below the lower limit mark on the dipstick, remove the oil filler cap/dipstick, and fill with the recommended oil to the upper limit mark.

Do not over fill.

5. Reinstall the oil filler cap/dipstick.




LM-AADAA.CDR

17

## Oil Change

Drain the engine oil when the engine is warm. Warm oil drains quickly and completely.


1. Place a suitable container next to the oil drain bolt area.
2. Wipe the oil filler area clean, then remove the oil filler cap/dipstick.
3. Remove the oil drain bolt and sealing washer and allow the oil to drain into a suitable container. After draining, install the drain bolt with the sealing washer and tighten it securely.



ZETFAAAB.CDR

4. Fill with the recommended oil. Do not overfill. Measure the oil level as shown on page 17.

Engine oil capacity: 0.65 l (0.69 US qt).



ZETFEAAA.CDR

Please dispose of used motor oil and the oil containers in a manner that is compatible with the environment. We suggest you take used oil in a sealed container to your local recycling center or service station for reclamation. Do not throw it in the trash or pour it on the ground or down a drain.

18

## SPARK PLUG

Recommended Spark Plugs: NGK BPR5ES

NIPPON DENSO W16EPR-U

The recommended spark plug is the correct heat range for normal engine operating temperatures.


### NOTICE

Incorrect spark plugs can cause engine damage.

For good performance, the spark plug must be properly gapped and free of deposits.


1. Disconnect the cap from the spark plug, and remove any dirt from the spark plug area.
2. Use the proper size plug wrench to remove the spark plug.
3. Inspect the spark plug. Replace it if damaged, badly fouled, if the sealing washer is in poor condition, or if the electrode is worn. If the spark plug is to be reused, clean it with a wire brush.

4. Measure the electrode gap with a suitable gauge. The correct gap is 0.70 - 0.80 mm (0.028 - 0.031 in). If adjustment is needed, correct the gap by carefully bending the side electrode.



ZETMAAAA.CDR

0.70 - 0.80 mm  
(0.028 - 0.031 in)



LM-AAKAA.CDR

21

5. Install the spark plug carefully, by hand, to avoid cross-threading. After the spark plug is seated, tighten with the proper size spark plug wrench to compress the washer.

When installing a new spark plug, tighten 1/2 turn after the spark plug seats to compress the washer.

When reinstalling the original spark plug, tighten 1/8 - 1/4 turn after the spark plug seats to compress the washer.

### NOTICE

A loose spark plug can become very hot and can damage the engine. Overtightening the spark plug can damage the threads in the cylinder head.


6. Attach the spark plug cap to the spark plug.

## IDLE SPEED ADJUSTMENT

1. Start the engine outdoors, and let it warm up to normal operating temperature.
2. Move the throttle control to the slowest position.
3. Using a screwdriver, turn the throttle stop screw to obtain the standard idle speed.

Standard Idle Speed:

N1 type: 1,700 ±150 rpm  
A1 type: 2,100 ±150 rpm



ZETFAAAA.CDR

22

## AIR CLEANER


A dirty air cleaner will restrict air flow to the carburetor and cause poor engine performance. Inspect the filter elements each time the engine is operated. You will need to clean the filter elements more frequently if you operate the engine in very dusty areas.

### NOTICE

Operating the engine without air filters, or with damaged filters, will allow dirt to enter the engine, causing rapid engine wear. This type of damage is not covered under warranty.

### Inspection

1. Remove the two wing bolts, then remove the air cleaner cover. Be careful to prevent dirt and debris from falling into the air cleaner base.
2. Remove the paper element and the foam filter from the air cleaner base.
3. Remove the foam filter from the paper element.
4. Inspect the filter elements. Replace damaged filters. Clean or replace dirty filters.



ZE7FACAA.CDR

19

## Cleaning

1. Remove the air cleaner cover and foam filter element, as described in the INSPECTION procedure (see page 19).
2. Remove the paper element from the air cleaner base.
3. Paper element: Tap the element several times on a hard surface to remove excess dirt, or blow compressed air [not exceeding 207 kPa (30 psi)] through the filter from the wire screen side. Never try to brush off dirt; brushing will force dirt into the fibers. Replace the paper element if it is excessively dirty.
4. Foam element: Clean in warm, soapy water or nonflammable solvent, rinse and dry thoroughly. Do not use gasoline as a cleaning solvent, because that would create a risk of fire or explosion. Dip the element in clean engine oil, then squeeze out all excess oil.

### NOTICE

Excess oil will restrict air flow through the foam filter and may transfer to the paper filter, soaking and clogging it.

5. Wipe dirt from the air cleaner base and cover using a moist rag. Be careful to prevent dirt from entering the air duct that leads to the carburetor.
6. Reinstall the air cleaner elements, and make sure both elements are properly positioned. Install the air cleaner cover and tighten the two wing bolts securely.

20

## SPARK ARRESTER (optional equipment)


In some areas, it is illegal to operate an engine without a USDA (United States Department of Agriculture)-qualified spark arrester. Check local laws and regulations. A USDA-qualified spark arrester is available from an authorized Honda servicing dealer.

The spark arrester must be serviced every 100 hours to keep it functioning as designed.

If the engine has been running, the muffler will be hot. Allow it to cool before servicing the spark arrester.

### Spark Arrester Removal


1. Remove the two nuts from the muffler shield, using a 10 mm wrench.
2. Remove the muffler heat shield, identification plate and muffler.
3. Remove the spark arrester from the muffler.



ZE2EAEAC.CDR

### Spark Arrester Cleaning And Inspection

1. Use a brush to remove carbon deposits from the spark arrester screen. Be careful not to damage the screen. Replace the spark arrester if it has breaks or has holes.
2. Install the spark arrester in the reverse order of removal.



ZE2EAEAB.CDR

23

## 8. TRANSPORTING

Keep the engine level when transporting to reduce the possibility of fuel leakage. Turn the fuel valve to the OFF position (see page 9).

## 9. STORAGE

### STORAGE PREPARATION

Proper storage preparation is essential for keeping your engine troublefree and looking good. The following steps will help to keep rust and corrosion from impairing your engine's function and appearance, and will make the engine easier to start when you use it again.

### Cleaning

If the engine has been running, allow it to cool for at least half an hour before cleaning.

24

Gasoline will oxidize and deteriorate in storage. Deteriorated gasoline will cause hard starting, and it leaves gum deposits that clog the fuel system. If the gasoline in your engine deteriorates during storage, you may need to have the carburetor, and other fuel system components, serviced or replaced.

The length of time that gasoline can be left in your fuel tank and carburetor without causing functional problems will vary with such factors as gasoline blend, your storage temperatures, and whether the fuel tank is partially or completely filled. The air in a partially filled fuel tank promotes fuel deterioration. Very warm storage temperatures accelerate fuel deterioration. Fuel problems may occur within a few months, or even less if the gasoline was not fresh when you filled the fuel tank.

Fuel system damage or engine performance problems resulting from neglected storage preparation are not covered under warranty.

You can extend fuel storage life by adding a gasoline stabilizer that is formulated for that purpose, or you can avoid fuel deterioration problems by draining the fuel tank and carburetor.

**Adding A Gasoline Stabilizer To Extend Fuel Storage Life**

When adding a gasoline stabilizer, fill the fuel tank with fresh gasoline. If only partially filled, air in the tank will promote fuel deterioration during storage. If you keep a container of gasoline for refueling, be sure that it contains only fresh gasoline.

1. Add gasoline stabilizer following the manufacturer's instructions.
2. After adding a gasoline stabilizer, run the engine outdoors for 10 minutes to be sure that treated gasoline has replaced the untreated gasoline in the carburetor.
3. Stop the engine, and turn the fuel valve to the OFF position (see page 9).

**10. TROUBLESHOOTING**


ENGINE WILL NOT START	POSSIBLE CAUSE	CORRECTION
1. Check throttle lever position.	Throttle lever in wrong position.	Move throttle lever to the choke position unless engine is warm (p. 8).
2. Check fuel.	Out of fuel.	Refuel (p.14)
	Fuel valve OFF.	Turn fuel valve ON (p. 8).
3. Remove and inspect spark plug.	Bad fuel; engine stored without treating or draining gasoline, or refueled with bad gasoline.	Drain fuel tank and carburetor (p. 26) Refuel with fresh gasoline (p. 15).
	Spark plug faulty, fouled, or improperly gapped.	Clean, gap, or replace spark plug (p. 21).
4. Take the engine to an authorized Honda servicing dealer, or refer to shop manual.	Spark plug wet with fuel (flooded engine).	Dry and reinstall spark plug. Start engine with throttle lever in FAST position.
	Fuel filter clogged, carburetor malfunction, ignition malfunction, compression problem.	Replace or repair faulty components as necessary.
LOSS OF POWER	POSSIBLE CAUSE	CORRECTION
1. Check air filters.	Air filters clogged.	Clean or replace air filters (p. 20)
2. Check fuel.	Bad fuel; engine stored without treating or draining gasoline, or refueled with bad gasoline.	Drain fuel tank and carburetor (p. 26) Refuel with fresh gasoline (p. 15).
3. Check throttle lever position.	Throttle lever in wrong position.	Position the throttle lever in fast (or high) position.
4. Take the engine to an authorized Honda servicing dealer, or refer to shop manual.	Fuel filter clogged, carburetor malfunction, ignition malfunction, compression problem.	Replace or repair faulty components as necessary.

**⚠ WARNING**


Gasoline is highly flammable and explosive and you can be burned or seriously injured when handling fuel.

- Stop engine and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

1. Remove the carburetor bowl drain bolt and gasket with a 10 mm wrench, and drain the carburetor bowl fuel into an approved gasoline container.



2. Move the fuel valve to the ON position (see page 8). This will allow the fuel tank to drain through the carburetor bowl.
3. After draining the carburetor and fuel tank, install the drain bolt and gasket and tighten securely.



Be sure the carburetor bowl is firmly seated against the carburetor body before tightening the drain bolt.

**11. GENERAL SPECIFICATIONS**

DIMENSIONS	GXV160K1A12	GXV160K1N12
Length x Width x Height mm (in)	415 x 359 x 354 (16.3 x 14.1 x 13.9)	
Dry Weight kg (lb)	14.8 (32.6)	14.6 (32.1)
Engine Type	4-stroke, overhead valve, single cylinder	
Displacement cc (cu in)	163 (9.9)	
Bore x Stroke mm (in)	68 x 45 (2.7 x 1.8)	
Maximum Output	5.5 hp @ 3,600 rpm	
Maximum Torque	1.05 kg.m (7.59 ft-lb) @ 2,500 rpm	
Fuel Consumption	340g/kWh 0.56 lb/hphr	
Cooling System	Forced Air	
Ignition System	CDI	
Lubrication System	Forced Splash	
PTO Shaft Direction	Counterclockwise	


**12. TUNEUP SPECIFICATIONS**

ITEM	SPECIFICATION	PAGE
Spark Plug Gap	0.70 - 0.80 mm (0.028 - 0.031 in)	21
Carburetor Idle Speed	1,700 ± 150 rpm	22
Valve Clearance (cold)	IN 0.15 ± 0.02 mm EX 0.20 ± 0.02 mm	See an authorized Honda servicing dealer *
Other Specifications	No other adjustments needed.	

Specifications may vary according to the types, and are subject to change without notice.

### Engine oil

1. Change the engine oil (see page 18).
2. Remove the spark plug (see page 21), and pour a tablespoon (5 - 10 cc) of clean engine oil into the cylinder. Using the recoil, crank the engine a few revolutions to distribute the oil in the cylinder, then reinstall the spark plug.



ZETEADAA.CDR

### REMOVAL FROM STORAGE

Check your engine as described in the PRE-OPERATION CHECKS section of this manual (see page 7).

If the fuel was drained during storage preparation, fill the tank with fresh gasoline. If you keep a container of gasoline for refueling, be sure it contains only fresh gasoline. Gasoline oxidizes and deteriorates over time, causing hard starting.

If the cylinder was coated with oil during storage preparation, the engine will smoke briefly at startup. This is normal.

### Storage

If your engine will be stored with gasoline in the fuel tank and carburetor, it is important to reduce the hazard of gasoline vapor ignition. Select a well-ventilated storage area away from any appliance that operates with a flame, such as a furnace, water heater, or clothes dryer. Also avoid any area with a spark-producing electric motor, or where power tools are operated.

If possible, avoid storage areas with high humidity, because that promotes rust and corrosion.

If there is gasoline in the fuel tank, leave the fuel valve in the OFF position (see page 9).

Keep the engine level in storage. Tilting can cause fuel or oil leakage.

With the engine and exhaust system cool, cover the engine to keep out dust. A hot engine and exhaust system can ignite or melt some materials. Do not use sheet plastic as a dust cover. A nonporous cover will trap moisture around the engine, promoting rust and corrosion.

27

28

## 13. CUSTOMER SERVICE INFORMATION

Honda engine dealership personnel are trained professionals. They should be able to answer any question you may have. If you encounter a problem that your dealer does not solve to your satisfaction, please discuss it with the dealership's management. The Service Manager or General Manager can help. Almost all problems are solved in this way.

If you are dissatisfied with the decision made by the dealership's management, contact the Honda Power Equipment Customer Service Office. You can write:

### American Honda Motor Co., Inc.

Honda Power Equipment Division  
Customer Service Office

4475 River Green Parkway  
Duluth, GA 30136-2565

Or telephone: (404) 497-6400

When you write or call, please give us this information:

- Model and serial numbers (see page 3)
- Name of the dealer who sold the engine to you
- Name and address of the dealer who services your engine
- Date of purchase
- Your name, address, and telephone number
- A detailed description of the problem

# HONDA

31

  
Printed on  
Recycled Paper

32

  
15009611  
PRINTED IN U.S.A.