

HD 25/15-4, HD 20/15-4, HD 16/15-4 Service Manual



| | | |
|----------|---|----------|
| 1 | Preface | 3 |
| 2 | Safety instructions | 3 |
| | 2.1 Hazard levels. | 3 |
| 3 | Technical Features | 3 |
| | 3.1 Validity. | 3 |
| | 3.2 Pump. | 3 |
| | 3.3 Drive | 3 |
| | 3.4 Electrical system | 3 |
| | 3.5 Frame | 3 |
| | 3.6 Accessories | 3 |
| | 3.7 Attachment sets. | 4 |
| 4 | Parts of the system | 4 |
| | 4.1 Type and information plates | 4 |
| | 4.2 Connection view | 4 |
| | 4.3 Pump Detail (HD 25/15-4) | 5 |
| | 4.4 Pump Detail (HD 20/15-4 und HD 16/15-4) | 5 |
| | 4.5 Front view | 6 |
| | 4.6 Rear view | 6 |
| | 4.7 View from the inside | 7 |
| 5 | Basic settings and service procedures | 8 |
| | 5.1 Cleaning the water filter. | 8 |
| | 5.2 Oil change | 8 |
| | 5.3 Removal of the crankshaft pump. | 8 |
| | 5.4 Removal of the crankshaft pump. | 10 |
| | 5.4.1 Pump diagram | 10 |
| | 5.4.2 Remove the crank drive | 11 |
| | 5.4.3 Cylinder head, uninstall | 12 |
| | 5.4.4 Overflow | 14 |
| | 5.4.5 Regulate the working pressure by means of the rotary knob on the gun | 16 |
| | 5.5 Electrical system | 17 |
| | 5.5.1 Open the switchbox | 17 |
| | 5.5.2 Remove the appliance switch rotary knob | 17 |
| | 5.5.3 Motor protection electronics | 18 |
| | 5.5.4 Functional description of the motor protection electronics: | 18 |
| | 5.5.5 Simple function test of the motor protection electronics without appli- ance | 19 |
| | 5.5.6 Gentle start electronics. | 19 |
| | 5.5.7 Simple function test of the gentle start electronics inside the appliance | 19 |
| | 5.5.8 Replacing the mains cable | 19 |
| | 5.6 Gun and spray pipe HD 20/15-4 and 20/15-4 | 19 |
| | 5.6.1 Disassemble hand spray gun | 19 |
| | 5.6.2 Adjustments on the power press regulator. | 21 |
| | 5.7 Gun HP 16/15-4 | 22 |
| | 5.8 Changing Wheels | 22 |

| | | |
|-----------|--|-----------|
| 6 | Troubleshooting | 23 |
| 6.1 | Appliance is not running | 23 |
| 6.2 | Indicator lamp | 23 |
| 6.2.1 | Operating status display | 23 |
| 6.2.2 | Fault indication | 23 |
| 6.3 | Device is not building up pressure | 23 |
| 6.4 | High pressure side is leaky | 23 |
| 6.5 | High pressure pump is vibrating | 23 |
| 7 | Technical specifications | 24 |
| 7.1 | Technical Documentation | 25 |
| 8 | Circuit diagram | 25 |
| 9 | Special tools | 25 |
| 10 | Tightening torques | 26 |
| 10.1 | HD 25/15-4 | 26 |
| 10.2 | HD 20/15-4 | 26 |
| 10.3 | HD 16/15-4 | 26 |
| 11 | Oil grades | 26 |

1 Preface

Good service work requires extensive and practice-oriented training as well as well-structured training materials.

Hence we offer regular basic and advanced training programmes covering the entire product range for all service engineers.

In addition to this, we also prepare service manuals for important appliances - these can be initially used as instruction guides and later on as reference guides.

Apart from this, we also regular information about product enhancements and their servicing.

If you should require supplements, have corrections or questions regarding this document, please address these citing the following subject to: *international-service@de.kaercher.com*

| | |
|----------|--------------------|
| Subject: | Fall 108234 |
|----------|--------------------|

The responsible product specialist will take care of your issue.

Copying and duplication of texts and diagrams as well as third-party access to this information is permitted only with the explicit permission of the company:

Alfred Kärcher GmbH & Co. KG
P O Box 160
D -71349 Winnenden
www.kaercher.com

2 Safety instructions

2.1 Hazard levels

⚠ Danger

Immediate danger that can cause severe injury or even death.

⚠ Warning

Possible hazardous situation that could lead to severe injury or even death.

Caution

Possible hazardous situation that could lead to mild injury to persons or damage to property.

3 Technical Features

3.1 Validity

This service manual applies to the following appliances:

- HD 25/15-4 (1.367-121.0)
- HD 20/15-4 (1.367-131.0)
- HD 16/15-4 (1.367-105.0)

The procedure for service work is the same for all three models. Device-specific features are emphasized in the text.

3.2 Pump

- 3 piston crankshaft pump
- Stainless steel piston with ceramic sleeves
- Cylinder head made of brass
- Pressure and suction valves made of stainless steel, valve cages made of plastic
- Built-in large water filter protects the pump from contamination. The filter can be easily removed and cleaned
- Oil level can be checked from the outside

3.3 Drive

- 4-pin, air-cooled three-phase motor with 1400 rpm.

3.4 Electrical system

- Automatic safety switch-off after 30 minutes of non-operation
- Winding protection contact
- The pressure switch on the overflow switches the motor contactor
- Soft start increases the motor speed gradually to 1,400 1/min and protects the circuit from overloads when switched on (HD 25/15-4)
- Electronics in spray water protected casing.

3.5 Frame

| | |
|------------|-----------------|
| HD 25/15-4 | Stainless steel |
| HD 20/15-4 | Steel, painted |
| HD 16/15-4 | Steel, painted |

3.6 Accessories

- Power nozzle, 25° spray angle
- **Dirt grinder**
- High pressure hose, NW 12 15 m (HD 25/15-4 and HD 20/15-4)
- High pressure hose NW 10 15 m (HD 16/15-4)
- Gun EasyPress (HD 16/15-4)
- Gun 300 bar (HD 20/15-4 and HD 25/15-4)

3.7 Attachment sets

| Attachment kit | Order number |
|--|--------------|
| Swivel casters | 2.851-042.0 |
| Hose drum | 2.440-002.0 |
| Operating hour counter | 2.851-066.0 |
| Breakdown-safe tyres | 2.851-067.0 |
| Two-jet pipe operation | 2.851-064.0 |
| Water filter with enlarged filter surface. | 2.851-065.0 |

4 Parts of the system

The case device offers free access to all components and is therefore easy to service.

4.2 Connection view

4.1 Type and information plates

The type and information plates are located:


- on the pump casing (pump specifications)
- in the accessories compartment (tyre pressure, nozzle size and oil types used)
- in the frame (general type plate with plant number)
- on the drive motor (performance data of electric motor)



- 1 Support leg (bow)
- 2 Water filter
- 3 Pump
- 4 Overflow casing and pressure regulation
- 5 Accessory compartment
- 6 Strut for crane loading
- 7 Push handle
- 8 Appliance electronics (electric box), appliance switch
- 9 Storage hook for cables and hoses
- 10 Drive motor connection box
- 11 Electric motor (drive)


12 Wheel, quick close cap

4.3 Pump Detail (HD 25/15-4)



- | | |
|--|--|
| 1 Water filter | 7 Crankshaft housing |
| 2 Water inlet | 8 Drive motor connection box |
| 3 Pressure switch | 9 Connecting flange for drive motor - pump |
| 4 Manometer | 10 Valve screws, pressure side |
| 5 Overflow casing, pressure regulation | 11 Pump head fastening screws |
| 6 Oil tank | 12 Valve screws, suction side |

4.4 Pump Detail (HD 20/15-4 und HD 16/15-4)



- | | |
|--|--|
| 1 Oil drain screw | 9 Overflow casing, pressure regulation |
| 2 Oil sight glass | 10 Water inlet |
| 3 Connecting flange for drive motor - pump | 11 Water filter |
| 4 Electro motor | 12 Type plate, pump |
| 5 Drive motor connection box | |
| 6 Valve screws, pressure side | |
| 7 Oil container plug | |
| 8 Manometer | |

4.5 Front view



- 1 Water filter
- 2 Water inlet
- 3 Oil drain screw

- 4 Oil sight glass
- 5 High-pressure outlet
- 6 Accessory compartment

4.6 Rear view



- 1 Indicator lamp
- 2 Power switch

- 3 Intake for hourmeter (option)

4.7 View from the inside



- 1 Lock detent
- 2 Accessory compartment
- 3 Information sign
- 4 Hinge, storage compartment
- 5 Cover
- 6 Lock pin
- 7 Type plate, appliance

5 Basic settings and service procedures

Service work on the appliance may only be performed by the authorized customer service. If so instructed in the operating instructions, the special tools indicated by KÄRCHER must be used.

⚠ Danger

Danger from electric current and liquids. While working on the appliance, pull the mains plug out of the socket and shut off the water supply

5.1 Cleaning the water filter



→ Turn the filter cup screws and pull it downwards along with the cup.



The individual parts of the water filter

- Check the water filter for contamination, clean if required.
- Assemble it back in the reverse sequence.

5.2 Oil change

- Unscrew the oil drain screw and collect used oil.
- Replace washers of the oil drain screw.
- Screw in the oil drain screws and tighten them.
- Slowly fill in new oil until the "MAX" marking on the oil sight glass.

5.3 Removal of the crankshaft pump


Drain the oil in a collection basin.




- Pull the support bow from the pressure switch.
- Remove the pressure switch.
- Check the diaphragm, replace if required.
- Unscrew the filter cup.



→ Loosen the screw connection at the motor flange.




→ Remove the high pressure pump casing; use a flat screwdriver for this.



→ Let the high pressure pump tilt down.

Note


Oil can leak during this tilting process.



→ Remove the high pressure pump from the electric motor.

5.4 Removal of the crankshaft pump

5.4.1 Pump diagram



- 1 Valve screw, suction side, with O-ring
- 2 Suction valve
- 3 Disc
- 4 Piston
- 5 Guide sleeve
- 6 Piston screw
- 7 Oil seal ring
- 8 Push bar
- 9 Pump casing
- 10 Bolt, push bar
- 11 Oil drain screw
- 12 Piston rod top
- 13 Crankshaft
- 14 Piston rod bottom
- 15 Piston rod screw
- 16 Oil bath
- 17 Crankshaft housing cover, with O-ring
- 18 Crankshaft bearing (1 x left, 1 x right)
- 19 Oil fill container
- 20 Distance-/labyrinth discs
- 21 Crown nut
- 22 Disc
- 23 Low pressure seal

- 24 Support ring, low pressure seal
- 25 Brass support disc
- 26 Disc
- 27 High pressure seal
- 28 Support ring, high pressure seal
- 29 Valve screw, pressure side, with O-ring
- 30 Pressure valve, with O-ring
- 31 Cylinder head

5.4.2 Remove the crank drive

- Unscrew the cylinder head. The exact procedure is described in the Chapter "Removing the cylinder head".
- Unscrew the pistons from the push rods.
- Unscrew the oil drain screw and collect oil.
- Remove the crankshaft casing cover.




- Mark the piston rod top and bottom. The piston rod tops and bottom must not be mixed up during installation.
- Remove the piston screws.
- Remove the piston bottoms.



- Remove the crankshaft bearing covers and the crankshaft bearings.
- Remove the crankshaft from the crankshaft casing.
- Pull out the piston with the push rods from the crankshaft casing.



- Remove the oil seal rings using a special pliers.




- 1 Oil fill container
- 2 Pump casing
- 3 Crankshaft bearing cover with crankshaft bearing and O-ring
- 4 Crankshaft casing cover
- 5 Piston rod bottom parts, marked
- 6 Crankshaft
- 7 Crankshaft bearing with flange, O-ring and shaft seal
- 8 Piston rod top parts, marked
- 9 Push rods

- Assembly in reverse order

- Note during assembly:

- Place the new oil seal in water prior to installation.
- Install the oil seal into the piston guide using an installation mandrel (special tool)
- Pay attention to installation position of the seals.




- 1 Motor shaft
- 2 Copper paste

- Grease the inside of the motor shaft with copper paste.
- Grease the outside of the crankshaft with copper paste.

Order no. copper paste (100g): 6.869-087.0

5.4.3 Cylinder head, uninstal

➔ Loosen the two fastening screws of the overflow (HD 25/15-4)




- 1 Valve screw, suction side
 - 2 Fastening screws
 - 3 **Pressure switch**
 - 4 Valve screw, pressure side
- ➔ Loosen the fastening screws.



➔ Carefully pull out the cylinder head using both hands.




The removed cylinder head cross section seal setup, see pump diagram.




- 1 Crown nut
- 2 Disc
- 3 Low pressure seal
- 4 Support ring, low pressure seal
- 5 Support disc, brass
- 6 Disc
- 7 High pressure seal
- 8 Support ring, high pressure seal
- 9 Cylinder head

➔ Always replace the entire set of seals.
 ➔ Grease the low and high pressure seals generously with special silicone grease prior to installation.
 Order no. silicone grease (100 g): 6.288-079.0



➔ Unscrew the valve screws to remove the valve cages.
 ➔ Pull the valve cage out with a pliers.


5.4.4 Overflow



Overflow setup


- 1 Screw socket
- 2 O ring
- 3 O ring
- 4 Nozzle insert
- 5 Manometer
- 6 Screw connections
- 7 Spring
- 8 Valve bolt
- 9 O ring
- 10 Valve seat
- 11 O ring
- 12 O ring
- 13 Valve seat
- 14 Spring
- 15 Valve bolt
- 16 O ring
- 17 Housing, overflow valve
- 18 O ring
- 19 Control piston
- 20 O ring
- 21 Spring plate, bottom

- 22 Spring
- 23 Spring plate, top
- 24 Sphere
- 25 Lock nut, adjustment screw, low pressure
- 26 Adjustment screw, low pressure
- 27 Spindle of the pressure/quantity regulation
- 28 Adjustment screw, high pressure
- 29 Lock nut, adjustment screw, high pressure
- 30 Turning handle
- 31 Node piece
- 32 Control piston, pressure switch
- 33 Membrane seal
- 34 Support bow, pressure switch
- 35 **Pressure switch**
- 36 O ring
- 37 O ring
- 38 Hollow screw
- 39 Hollow screw
- 40 O ring
- 41 O ring
- 42 Manometer




Cross section of the overflow

- | | |
|---|-----------------------------------|
| 1 Turning handle | 21 Nozzle insert |
| 2 Lock nut, adjustment screw, high pressure | 22 O ring |
| 3 Adjustment screw, high pressure | 23 Screw socket |
| 4 Spindle, pressure and quantity regulation | 24 O ring |
| 5 Spring plate, top | 25 O ring |
| 6 Sphere | 26 Spring |
| 7 Adjustment screw, low pressure | 27 Valve bolt |
| 8 Lock nut, adjustment screw, low pressure | 28 O ring |
| 9 Spring | 29 Node piece |
| 10 Housing, overflow valve | 30 Hollow screw, suction side |
| 11 Spring plate, bottom | 31 Valve seat |
| 12 Manometer | 32 Hollow screw, pressure side |
| 13 Control piston | 33 O ring |
| 14 O ring | 34 Disc |
| 15 O ring | 35 O ring |
| 16 O ring | 36 Control piston |
| 17 Valve seat | 37 Membrane seal, pressure switch |
| 18 O ring | 38 Protective cover |
| 19 Valve bolt | 39 Casing |
| 20 Spring | 40 Spring |
| | 41 O ring |



- Loosen both hollow screws at the same time to remove the overflow casing in order not to damage the O-rings.

5.4.5 Regulate the working pressure by means of the rotary knob on the gun



- 1 Adjustment screw, high pressure
- 2 Lock nut, adjustment screw, high pressure
- 3 Spindle, pressure and quantity regulation
- 4 Adjustment screw, low pressure
- 5 Lock nut, adjustment screw, low pressure
- 6 Housing, overflow valve

Preparation

- Fasten the test manometer to the high-pressure connection.
- Connect the high-pressure hose with the servo press hand spray gun to the test manometer.

Setting the maximum working pressure:

- Rotate the servo press to the "MIN" position, open the hand spray gun and let the device run.
- Turn in the rotary handle of the pressure and quantity regulation until it stops (MAX value).
- Pull off the rotary handle.
- Loosen the locknut for high pressure.
- Turn the adjustment screw high pressure so that the pressure display on the test manometer

equals the maximum working pressure in the Chapter "Specifications".

- Secure the adjustment screw for high pressure by tightening the locknut.
- Seal the adjustment screw for high pressure and the lock nut with locking paint.


Setting the minimum working pressure:

- Install the new high pressure nozzle.
- Rotate the servo press to the "MAX" position, open the hand spray gun and let the device run.
- Pull off the rotary handle.
- Loosen the locknut for low pressure.
- Turn the adjustment screw low pressure and the spindle for pressure/quantity regulation at the same time, so that the pressure display on the test manometer equals the minimum working pressure in the Chapter "Specifications".
- Secure the adjustment screw for low pressure by tightening the locknut.
- Seal the adjustment screw for high pressure and the lock nut with locking paint.

5.5 Electrical system

⚠ Warning

When working on the device, please always use the current circuit diagram in Kärcher-Inside.



- 1 Power contactor
- 2 Terminal strip
- 3 Terminal strip protective conductor
- 4 Motor protection electronics
- 5 Fuse F1 (1.0 AT)
- 6 Gentle start electronics
- 7 Control transformer (fuse 2.0 AT)
- 8 Cover of switchbox

5.5.1 Open the switchbox

→ Loosen 4 screws and remove the lid of the casing.




→ Carefully pull the indicator lamp out of the socket in the lid and place the lid on the side.

5.5.2 Remove the appliance switch rotary knob




→ Carefully remove the lid cap
→ Loosen the screw on the shaft and remove the knob



- 1 Shaft seal
- 2 Indicator lamp
- 3 Indicator lamp (no function)

- The resistance to spray water is ensured by a seal on the shaft.
- Loosen the 4 fastening screws.
- Disconnect the cable connections.
- Remove the appliance switch.
- Assemble it back in the reverse sequence.

5.5.3 Motor protection electronics



- 1 Protective conductor connection
- 2 Measuring coil
- 3 DIP switch
- 4 Measuring coil
- 5 Fuse 1.0 AT
- 6 Terminal strips
- 7 Indicator lamp connection

The electronics can only be replaced as one complete unit. Prior to the replacement, check the cable connections, connected components and fuses. Connect power supply and control wires according to the circuit plan.

5.5.4 Functional description of the motor protection electronics:

Position of the DIP switches:

| Switch | Position | Meaning |
|--------|----------|--|
| 1 | OFF | 1-phase appliance |
| 2 | ON | Trailing time 30 seconds |
| 3 | ON | Leak detection |
| 4 | ON | Switch off after 30 minutes of continuous operation / pause. |

Display of the indicator lamp:

| Blinking | Colour | Meaning |
|----------|--------|--|
| -- | Green | Operation, voltage present, no faults |
| Duration | Green | 30 minutes of continuous operation, continuous pause |
| 1x | Red | Leak in the system |
| 2x | Red | Winding protection contact was triggered |
| 3x | Red | Over or under voltage, current asymmetry |
| 4x | Red | Overcurrent |

Switch-off after 30 minutes of continuous operation or continuous break:

- Indicator lamp is blinking green
- Machine switches off and locks up, if there is no signal change from the pressure switch after another 30 minutes.
- A signal change will restart the time.
- DIP switch 4: OFF = without switch-off, ON = with switch-off.

Leak

- 1 blink red.
- Switch-off and locking of the machine after 10 short starts (less than 2 seconds) due to a leak.
- DIP switch 3: OFF = without switch-off, ON = with switch-off.

Winding protection contact

- blinks red twice:
- Switch-off and locking of the machine, if the winding protection contact opens.

Over or under voltage, current asymmetry

- blinks red thrice:
- Switch-off and locking of the machine in case the secondary voltage of the control transformer is less than 17 volts AC (under voltage).
- Switch-off and locking of the machine in case the secondary voltage of the control transformer is more than 37 volts AC (over voltage).
- Switch-off and locking of the machine in case of a current difference on the transformers of more than 10 A for two seconds.

Overcurrent

- Switch-off and locking of the machine in case of an over voltage of 42 A on one of the transformers.

One-phase operation

- DIP switch 1: ON = one-phase appliance, OFF = three-phase appliance.
- In the one-phase appliance, only one transformer is used.

Operation with gentle start

- In appliances with gentle start, the trailing must be active.
 - When the pressure switch is opened, the pump will shut off with a 30 second delay.
 - DIP switch 2: ON = trailing active, OFF = trailing off
- Switch the appliance off and back on to delete a fault display.

5.5.5 Simple function test of the motor protection electronics without appliance

- Connect the indicator lamp.
- Use a wire jumper on terminals 3 + 4.
- Use a wire jumper on terminals 5 + 6.
- Connect a contactor coil to terminals 7 + 8.
- Connect voltage (24V~) to terminals 9 + 10.
- Switch on the voltage supply.


The contactor must react the indicator lamp must glow green.

5.5.6 Gentle start electronics

The appliance is equipped with gentle start electronics.

Soft start increases the motor speed gradually to 1,400 1/min and protects the circuit from overloads when switched on

The electronics can only be replaced as one complete unit. Prior to the replacement, check the cable connections, connected components and fuses.



- A Phase indicator
- B Phase indicator
- C Voltage supply 24V
- D Connection release
- E Display "On" lights up for voltage supply of 24V, display "Run" lights up after the motor has been started.

Possible reasons for malfunctions of the gentle start electronics:

- Overvoltage of the voltage supply (more than 27V)
- Multiple motor starts per minute (30 seconds of trailing control of the motor protection electronics is not active).
- Corrosion and/or moisture in the components.

5.5.7 Simple function test of the gentle start electronics inside the appliance

- Check whether both phases are present.
- Check if the voltage supply (24V~) is present.
- Jump the release on X1 5/6 (D top of image).
- LED "RUN" on the circuit board lights up after 1 - 2 seconds.

5.5.8 Replacing the mains cable




1 Fastener

2 Disc

- Pull out the safety bow of the traction relief.
- Loosen the disc.
- Take out the traction relief from the holder.
- Disconnect the mains cable.
- Assemble it back in the reverse sequence.
- The disc must be under the safety bow.

5.6 Gun and spray pipe HD 20/15-4 and 20/15-4

The illustration might differ from the gun on your model, however, the procedure is still the same.




- 1 Connection of high pressure hose
- 2 Hand lever
- 3 Gun
- 4 Power press regulator
- 5 Hand guide
- 6 Spray pipe (stainless steel)
- 7 Nozzle

5.6.1 Disassemble hand spray gun

The hand spray gun can be disassembled to replace seals or wear parts.



Hand-spray gun



The individual parts of the hand spray gun. Part numbers, see DISIS.

1 Support ring

2 O ring

→ Unscrew all fastening screws.

→ Remove the half of the handle shell.



The open gun, trigger lock removed.



→ Remove the lever; press out the pin on the joint.



→ Unscrew the locking screw; use a 12 mm hexagon socket wrench.



→ Pull the pin out toward the front.



→ Press the piston out from the front. Make sure that the springs do not jump out.

5.6.2 Adjustments on the power press regulator



The removed piston with springs and seal set

→ Adhere to the sequence of the seal set and the springs when assembling.



→ The seal set includes an O-ring 14x1,5-NBR 70.



→ Open the screw connection.




→ Replace the support ring and the O-ring.

→ During the assembly, ensure the correct installation sequence of the O-ring and the support ring.

Note

Grease all O-rings with Ontropeen (part number: 6.288-088.0 5 grams, 6.288-079.0 100 grams). Fill the hollow spaces with grease.

→ Reassemble the hand spray gun in the reverse sequence.




- 1 Ceramic disc on spray pipe side
- 2 Ceramic disc on gun side

The ceramic disc on the gun side is rigidly connected to the gun connection. The ceramic disc on the spray pipe side is connected to the regulator and therefore adjustable.


Offset holes in the ceramic discs can adjust the flow volume when rotating the discs. This illustration shows the two overlapping ceramic discs and the water flow (blue) with different opening angles (from 0° to 90°).

With the minimal setting, the water flows through a small hose in the middle of the ceramic discs.



Cross section of the power press regulator (gun side)


- 1 Ceramic disc on gun side
- 2 Casing of rotating regulator
- 3 Connecting pin
- 4 Handle of rotary regulator



Longitudinal section of the power press regulator

- 1 Gun connection
- 2 Connecting pin
- 3 Ceramic disc on gun side
- 4 Ceramic disc on spray pipe side
- 5 Casing of rotating regulator
- 6 Handle of rotary regulator
- 7 Spray pipe connection

5.7 Gun HP 16/15-4



- 1 Safety catch
- 2 Halves of the handle shell
- 3 Lever
- 4 High pressure hose
- 5 Safety pin
- 6 coupling
- 7 Spring
- 8 Valve ball
- 9 Piston
- 10 Spray pipe connection
- 11 O-rings/support ring

When this lever is actuated, the valve ball is pressed against the spring toward the bottom by the piston. The node piece is completely replaced during the repair procedure.

5.8 Changing Wheels



→ Remove the quick connect with pliers. The quick connect cannot be reused.



- Remove the wheel, watch for the spacer.
- Grease the axle with silicone.



→ Install the quick connect with the proper installation aid and a rubber mallet.

6 Troubleshooting

6.1 Appliance is not running

- No power
- Check whether the voltage indicated on the type plate corresponds to the voltage of the socket.
- Check the mains connection cable for damages.
- Indicator lamp is blinking green
- Operational readiness period has expired. Switch on/off the appliance again.
- The water shortage fuse (option) was triggered due to low water inlet pressure. The indicator lamp "lack of water" will illuminate.
- Check water inlet pressure, minimum value see "Specifications".
Turn the device switch to "0" and turn on again to restart the system.
- Motor overloaded/ over-heated or electrical circuit breaker or winding protection switch has got released.
- Switch off appliance and let it cool down. Remove the cause of the problem. Turn on the appliance again.

6.2 Indicator lamp

The indicator lamps display the operating states (green) and interruptions (red).

Reset:

- Set the appliance switch to "0".
- Wait for a while.
- Set the appliance switch to "I".

6.2.1 Operating status display

- Continuous green:
 - The appliance is now ready for operation.
- 1x blinking green:
 - Operational readiness has expired after 30 minutes.
 - The appliance has switched off after 30 minutes of continuous operation (safety if the high pressure hose bursts).

6.2.2 Fault indication

- Continuous red light:
 - Electrical problems in appliance
 - Pull out the mains plug.
 - Call Customer Service.
- 1x blinking red:
 - High pressure side is leaky
 - Check high pressure hose, hose connections and hand spray gun for leaks.
- 2x blinking red:
 - Engine overload/overheat
 - Set the appliance switch to "0".
 - Allow device to cool down.
 - Set the appliance switch to "I".
 - Water pressure is too low

- Ensure adequate water line pressure.
- 3x blinking red:
 - Fault in the voltage supply
- Check main connections and mains fuse.
- 4x blinking red:
 - Power consumption is too high
- Call Customer Service.

6.3 Device is not building up pressure

- Wrong nozzle
- Check nozzle for correct size (see technical specifications).
- Flushed the nozzle.
- Clean/ replace nozzle.
- Filter is dirty.
- Clean filter at the water connection.
Unscrew the filter casing, remove the filter, clean it and replace it.
- Air within the system
- Appliance ventilation:
Unscrew the nozzle. Switch on the appliance and let it run until the water exiting from the spray pipe is bubble-free. Switch off the appliance and fit the nozzle again.
- Pipe inlets to pump are leaky or blocked
- Check all supply lines to the pump for leaks or blockages.

6.4 High pressure side is leaky

- 3 drops per minute are permitted and can come out from the lower side of the appliance.

6.5 High pressure pump is vibrating

- Check all supply lines to the high-pressure pump for leaks or blockages.
- Appliance ventilation:
Unscrew the nozzle. Switch on the appliance and let it run until the water exiting from the spray pipe is bubble-free. Switch off the appliance and fit the nozzle again.

7 Technical specifications

| Type | | HD 25/15-4 | HD 20/15-4 | HD 16/15-4 |
|---|------------------|----------------------|----------------------|----------------------|
| Power connection | | | | |
| Voltage | V | 400 | 400 | 400 |
| Current type | Hz | 3~50 | 3~50 | 3~50 |
| Connection output | kW | 13 | 11,5 | 9,5 |
| Current pickup, full load (after 1 minutes) | A | <25 | <21 | <16 |
| Mains fuse (slow-blow) | A | 25 | 25 | 16 |
| Maximum allowed net impedance | Ohm | (0,072+j0,045) | (0,072+j0,045) | (0,072+j0,045) |
| Water connection | | | | |
| Max. feed temperature | °C | 60 | 60 | 60 |
| Min. feed volume | l/h (l/min) | 3000 (50) | 2500 (42) | 2000 (34) |
| Inlet hose length (min.) | m | 7,5 | 7,5 | 7,5 |
| Inlet hose diameter (min.) | Inch | 3/4 | 3/4 | 3/4 |
| Suck height from open container (20 °C) | m | 0,5 | 0,5 | 0,5 |
| Performance data | | | | |
| Working pressure (appliance manometer) | MPa (bar) | 3...15 (30...150) | 3...15 (30...150) | 3...15 (30...150) |
| Servopress pressure (manometer on the appliance outlet) | MPa (bar) | 14,8 (148) | 15 (150) | 15,3 (153) |
| Max. permissible pressure | MPa (bar) | 19,5 (195) | 19,5 (195) | 19,5 (195) |
| Water flow rate | l/h (l/min) | >2320 (>39) | >1900 (>32) | >1520 (>25) |
| Nozzle size | -- | 155 | 125 | 100 |
| Recoil force of trigger gun | N | 120 | 96 | 77 |
| Noise emission | | | | |
| Sound pressure level (EN 60704-1) | dB(A) | 76 | 80 | 79 |
| Guaranteed sound power level (2000/14/EC) | dB(A) | 93 | 93 | 98 |
| Machine vibrations | | | | |
| Vibration total value (ISO 5349) | | | | |
| Hand spraygun | m/s ² | 3,2 | 3,2 | 1,7 |
| Spray lance | m/s ² | 6,4 | 6,4 | 2,8 |
| Fuel | | | | |
| Oil quantity - pump | l | 1,3 | 1,3 | 1,3 |
| Oil type - pipe | | SAE 90 | SAE 15W40 | SAE 15W40 |
| Dimensions and weights | | | | |
| Length x width x height | mm | 957 x 686 x 1080 | | |
| Weight without accessories | kg | 119 | | |
| Air pressure of wheels | MPa (bar) | 0,25 (2,5) | | |

7.1 Technical Documentation

| Appliance type | Order number | Circuit diagram | operating instructions | Spare parts list |
|-----------------|--------------|-----------------|------------------------|------------------|
| HD 25/15-4 Cage | 1.367-121.0 | 0.089-091.0 | 5.963-304.0 | 5.971-040.0 |
| HD 20/15-4 Cage | 1.367-131.0 | 0.089-091.0 | 5.963-304.0 | 5.971-077.0 |
| HD 16/15-4 Cage | 1.367-105.0 | 0.089-091.0 | 5.963-304.0 | 5.971-077.0 |

8 Circuit diagram

The status of the attached circuit diagram represents the creation date of the service manual. This circuit diagram is not updated. When working on the device, please always use the current circuit diagram in Kärcher-Inside.

9 Special tools

| Special tool HP 25/15-4 and 20/15-4, piston diameter 25 mm | Order number |
|--|--------------|
| Pliers to remove the rings and seats | 4.901-062.0 |
| Inner driver, diameter 14.5 to 18.5 mm | 6.815-013.0 |
| Installation mandrel, high and low pressure seal | 6.815-211.0 |
| Installation sleeve, high pressure seal | 6.815-214.0 |
| Installation mandrel, oil seal | 6.815-223.0 |
| Insertion tool, crown wrench | 6.815-209.0 |

| Special tool HP 20/15-4, piston diameter 25 mm | Order number |
|--|--------------|
| Pliers to remove the rings and seats | 4.901-062.0 |
| Inner driver, diameter 14.5 to 18.5 mm | 6.815-013.0 |
| Installation mandrel, high and low pressure seal | 6.815-257.0 |
| Installation sleeve, high pressure seal | 6.815-256.0 |
| Installation mandrel, oil seal | 6.815-258.0 |

| Special tool HP 16/15-4, piston diameter 22mm | Order number |
|--|--------------|
| Pliers to remove the rings and seats | 4.901-062.0 |
| Inner driver, diameter 14.5 to 18.5 mm | 6.815-013.0 |
| Installation mandrel, high and low pressure seal | 6.815-257.0 |
| Installation sleeve, high pressure seal | 6.815-256.0 |
| Installation mandrel, oil seal | 6.815-258.0 |

10 Tightening torques

10.1 HD 25/15-4

| | |
|---------------------------------|----------|
| Gear cover | 5 Nm |
| Hollow screws on cylinder head | 50 Nm |
| Crown nut | 50 Nm |
| Valve screws | 50 Nm |
| Cylinder head screws | 40 Nm |
| Piston screws | 20 Nm |
| Oil drain screw | 40 Nm |
| Crankshaft bearing cover screws | 18-22 Nm |
| Piston rod screws | 18-22 Nm |

10.2 HD 20/15-4

| | |
|---------------------------------|----------|
| Gear cover | 11 Nm |
| Hollow screws on cylinder head | 50 Nm |
| Valve screws | 200 Nm |
| Cylinder head screws | 40 Nm |
| Piston screws | 15 Nm |
| Oil drain screw | 40 Nm |
| Crankshaft bearing cover screws | 25 Nm |
| Piston rod screws | 18-22 Nm |

10.3 HD 16/15-4

| | |
|---------------------------------|----------|
| Gear cover | 11 Nm |
| Hollow screws on cylinder head | 50 Nm |
| Valve screws | 200 Nm |
| Cylinder head screws | 40 Nm |
| Piston screws | 15 Nm |
| Oil drain screw | 40 Nm |
| Crankshaft bearing cover screws | 25 Nm |
| Piston rod screws | 18-22 Nm |

11 Oil grades

| | |
|------------|-----------|
| HD 25/15-4 | SAE 90 |
| HD 20/15-4 | SAE 15W40 |
| HD 16/15-4 | SAE 15W40 |