


Spare parts list

(1.445-160.0) LBL 4 Battery Set *EU


Table of contents

LBL 4 Battery Set *EU (1.445-160.0)	3
1 Blower complete 36V	5
25 Guide rail battery packaged 36V (4.445-029.3)	7




LBL 4 Battery Set *EU (1.445-160.0)

POS	Article no.	Description	Quantity	Unit	Remark
1		Blower complete 36V	1	PC	
2	2.445-030.0	Battery Power 36/25 DW *INT	1	PC	36V/2,5Ah
3	2.445-031.0	Battery Power 36/50 DW *INT	1	PC	36V/5,0Ah
4	6.445-051.3	Plug-in charger Battery Power 36/5 *EU	1	PC	*EU
5	2.445-033.0	Fast battery recharger Battery Power 36 V *EU	1	PC	36V/2,5A *EU
6	2.445-045.0	Battery charger Battery Power+ 36/60 *EU	1	PC	36V/6,0A *EU
7	2.445-054.0	Uni-Charger Battery Power+ 18-36/60 *EU	1	PC	18-36V/2,5-6A *EU
61		Flyer battery platform 2020	1	PC	



1 Blower complete 36V

POS	Article no.	Description	Quantity	Unit
1	4.445-074.0	Housing set	1	PC
2	5.445-062.3	Blow pipe rear packaged	1	PC
3	5.445-063.3	Blow pipe front packaged	1	PC
4	5.445-070.3	Nozzle flat packaged	1	PC
5	6.303-122.0	M4 .2X13 DIN 7981 TORX T15 PAN HD HI/LO	9	PC
9	6.445-017.3	Motor packaged 36V	1	PC
10	5.445-074.0	Support motor 36V	1	PC
12	5.445-150.0	Blower set 36V	1	PC
16	5.445-066.3	Cover plate motor packaged	1	PC
20	5.445-076.3	Button packaged 36V	1	PC
22	4.445-027.3	Cover plate air inlet packaged	1	PC
25	4.445-029.3	Guide rail battery packaged 36V	1	PC
30	5.445-073.3	Label packaged 36V	1	PC
40	6.630-836.3	Micro switch for replacement	2	PC



25 Guide rail battery packaged 36V (4.445-029.3)

POS	Article no.	Description	Quantity	Unit
20	6.445-018.3	Main Board packaged	1	PC