

Spare parts list

(5.970-725.0) Spare parts list SDP 7000

Table of contents


Spare parts list SDP 7000 (5.970-725.0)	3
10 Individual parts	4
11 Individual parts	5
12 Individual parts	7

Spare parts list SDP 7000 (5.970-725.0)

POS	Description	Quantity	Unit
10	Individual parts	1.000	ST


10 Individual parts

POS	Description	Quantity	Unit	Foot note text
12	Individual parts	1.000	ST	VERSION 2
11	Individual parts	1.000	ST	VERSION 1



11 Individual parts

POS	Article no.	Description	Quantity	Unit	Remark
4	7.311-067.0	Hexagon nut M 6-A2-70 ISO 4032	1.000	ST	
1	4.645-090.0	Hose connection complete OPP	1.000	ST	
2	5.645-061.0	Impeller dirt	1.000	ST	SDP 7000 /*EU/*CH/*GB /D=90,5 mm
2	5.645-208.0	Impeller SDP5000	1.000	ST	SDP 5000 /*EU/*CH/*GB /D=90,5 mm
2	5.645-375.0	Impeller SDP7000 *MX	1.000	ST	SDP 7000 /*MX /D=90,5 mm
3	7.312-292.0	Washer 6 -A2 ISO 7093-1	1.000	ST	



12 Individual parts

POS	Article no.	Description	Quantity	Unit	Remark
3	7.311-514.0	Hexagon nut M 8-A2-70 ISO 7040	1.000	ST	
10	4.645-090.0	Hose connection complete OPP	1.000	ST	
2	5.645-921.0	Impeller Ø86 SDP 5000	1.000	ST	/D=86 mm