

Materiāla Nr. ⚙ Nosaukums ⚙ Konstruktiju grupa ⚙ Ierīce ⚙

5.581-035.0	Valve seat		Control panel	HDS 1295 SX Eco*EU-I (1.028-323.0)
5.581-035.0	Valve seat		Control panel	HDS 1295 SX *EU (1.028-320.0)
5.581-035.0	Valve seat		Control panel	HDS 1295-FLAMM*EU-I (1.028-306.0)
5.581-035.0	Valve seat		Control panel	HDS 2000 SUPER *EU (1.071-261.0)
5.581-035.0	Valve seat		Control panel	HDS 2000 SUPER *EU-I (1.071-100.0)
5.581-035.0	Valve seat		Control panel	HDS 2000 super (1.071-111.0)
5.581-035.0	Valve seat		Control panel	HDS 1295 SX *EU (1.028-321.0)
5.581-035.0	Valve seat		Control panel	HDS 1295 S ECO*EU-II (1.028-308.0)
5.581-035.0	Valve seat		Control panel	HDS 1295 -4SX ECO LL*EU-I (1.028-324.0)
5.581-035.0	Valve seat		Control panel	HDS 1295 -4S ECO LL*EU-I (1.028-311.0)
5.581-035.0	Valve seat		Control panel	HDS 1295 -FLAMM *SE (1.028-861.0)
5.581-035.0	Valve seat		Control panel	HDS 1295 S ECO *AU (1.028-309.0)
5.581-035.0	Valve seat		Control panel	HDS 1295 S ECO*EU-I (1.028-307.0)
5.581-035.0	Valve seat		Control panel	HDS 2000 SUPER(420V 3PH) (1.071-281.0)
5.581-035.0	Valve seat		Control panel	HDS 5.0/30 (1.028-342.0)
5.581-035.0	Valve seat		Control panel	HDS 801E-24KW *CA (1.030-701.0)
5.581-035.0	Valve seat		Control panel	HDS 801E-24KW (1.030-681.0)
5.581-035.0	Valve seat		Control panel	HDS 801E-24KW*GB/AU (1.030-461.0)
5.581-035.0	Valve seat		Control panel	HDS 801E-24KW*GB/AU (1.030-461.0)
5.581-035.0	Valve seat		Control panel	SB-HDS 695-WERT *EU (1.025-941.0)
5.581-035.0	Valve seat		Control panel	HDS 801 E-12KW *GB (1.030-281.0)
5.581-035.0	Valve seat		Control panel	HDS 801 E-12KW *GB (1.030-281.0)
5.581-035.0	Valve seat		Control panel	HDS 801 e *EU (1.030-131.0)
5.581-035.0	Valve seat		Control panel	HDS 5.0/30-4S Eb (1.028-341.0)
5.581-035.0	Valve seat		Control panel	HDS 801 e *EU (1.030-131.0)
5.581-035.0	Valve seat		Control panel	HDS 801E (1.030-111.0)
5.581-035.0	Valve seat		Control panel	HDS 801E (1.030-111.0)
5.581-035.0	Valve seat		Control panel	HDS 1295 200V 60HZ *JP (1.028-751.0)
5.581-035.0	Valve seat		Control panel	HDS 1295 200V 50HZ *JP (1.028-741.0)
5.581-035.0	Valve seat		Control panel	HDS 1195 *AU-GB (1.028-902.0)
5.581-035.0	Valve seat		Control panel	HDS 1195 *EU-II (1.028-336.0)
5.581-035.0	Valve seat		Control panel	HDS 1195 *AR (1.028-335.0)
5.581-035.0	Valve seat		Control panel	HDS 1195 *AR (1.028-904.0)
5.581-035.0	Valve seat		Control panel	HDS 1195 S ECO *GB (1.028-339.0)
5.581-035.0	Valve seat		Control panel	HDS 1195 4M Eco *AU (1.028-343.0)

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

5.581-035.0 Valve seat

Control panel HDS 1195 *EU-I (1.028-333.0)
Control panel HDS 1195 * VEX (1.028-791.0)
Control panel HDS 1195 (1.028-332.0)
Control panel HDS 1195 (1.028-681.0)
Control panel HDS 1195 *GB (1.028-331.0)
Control panel HDS 1195 *VEX (1.028-334.0)
Control panel HDS 1195 *VEX (1.028-781.0)
Control panel HDS 1195 S ECO *KAP (1.028-340.0)
Control panel HDS 1195 S ECO (1.028-337.0)
Control panel HDS 1295 *EU (1.028-261.0)
Control panel HDS 1295 *EU (1.028-261.0)
Control panel HDS 1295 *EU-I (1.028-301.0)
Control panel HDS 1295 *EU-II (1.028-302.0)
Control panel HDS 1295 *GB/AU (1.028-281.0)
Control panel HDS 1295 *EU (1.028-111.0)
Control panel HDS 1295 *AU (1.028-303.0)
Control panel HDS 1195 SX *EU-I (1.028-351.0)
Control panel HDS 1195 S ECO*EU-II (1.028-338.0)
Control panel HDS 1195 SX *EU-II (1.028-352.0)
Control panel HDS 1195 SX ECO *EU-II (1.028-354.0)
Control panel HDS 1195 SX ECO*EU-I (1.028-353.0)
Control panel HDS 1150 -4S Basic *EU-I (1.028-355.0)