


## **Spare parts list**

(5.973-073.0) Spare parts list Deluxe Irrigation Set

## Table of contents

---

Spare parts list Deluxe Irrigation Set (5.973-073.0)	3
1 SensoTimer ST6 Duo eco!ogic (2.645-214.0)	5
Spare parts list ST 6 duo (5.973-031.0)	6
10 Individual parts	7



Spare parts list Deluxe Irrigation Set (5.973-073.0)

POS	Article no.	Description	Quantity	Unit
10	6.465-031.0	Connection 3/4	1	PC
5	2.645-234.0	DRIP NOZZLE	2	PC
6	2.645-237.0	Ground spike 5x	3	PC
8	2.645-176.0	Hose coupling set 1/2", 5/8" OPP	1	PC
4	2.645-233.0	HOSE STOP	3	PC
3	2.645-232.0	I-CONNECTOR	2	PC
15	2.645-235.0	Sealing collar 5x	2	PC
1	2.645-214.0	SensoTimer ST6 Duo eco!ogic	1	PC
12	2.645-229.0	SOAKER HOSE 1/2" -10M	1	PC
16	2.645-236.0	Spray collar set 5x	2	PC
11	2.645-227.0	System hose 1/2"	1	PC
2	2.645-231.0	T-CONNECTOR WITH WATER FLOW REGULATION	2	PC
17	2.645-007.0	Tap adaptor with reducer G1	1	PC

1 SensoTimer ST6 Duo ecologic (2.645-214.0)



---

POS	Article no.	Description	Quantity	Unit
0	5.973-031.0	Spare parts list ST 6 duo	1	PC

Spare parts list ST 6 duo (5.973-031.0)

---

POS	Description	Quantity	Unit
10	Individual parts	1	PC



## 10 Individual parts

---

<b>POS</b>	<b>Article no.</b>	<b>Description</b>	<b>Quantity</b>	<b>Unit</b>
9	5.645-806.0	Cap	2	PC
6	6.465-031.0	Connection 3/4	2	PC
12	5.645-807.0	Cover sensor	2	PC
5	6.645-514.0	Filter for G1	1	PC
3	4.645-483.0	Multi Valve	1	PC
2	6.645-673.0	O-Ring seal 70x2,5	1	PC
1	4.645-480.0	Operating unit	1	PC
10	6.303-557.0	Screw 3x12 Kombitorx T8	6	PC
8	4.645-499.0	Sensor	2	PC
11	2.645-242.0	Sensor Pad 2er Set	2	PC
4	2.645-007.0	Tap adaptor with reducer G1	1	PC