

## **Spare parts list**

(4.117-037.0) Triple jet nozzle TR 050

## Table of contents

---


904 Triple jet nozzle TR 050 (4.117-037.0)	3
1 Triple jet nozzle TR 050	4

---

904 Triple jet nozzle TR 050 (4.117-037.0)

---

POS	Description	Quantity	Unit
1	Triple jet nozzle TR 050	1.000	ST



## 1 Triple jet nozzle TR 050

---

<b>POS</b>	<b>Article no.</b>	<b>Description</b>	<b>Quantity</b>	<b>Unit</b>
15	6.363-696.0	Brake ring 14x20x3	1.000	ST
12	5.321-884.0	Clamp	1.000	ST
4	5.311-225.0	Nut	1.000	ST
6	6.362-480.0	O-Ring seal 12,42x 1,78	1.000	ST
7	6.362-460.0	O-Ring seal 14,0 X 2,5-NBR 70	1.000	ST
10	6.362-409.0	O-Ring seal 32,0 X 1,5	1.000	ST
2	5.394-859.0	Protection part	1.000	ST
11	7.401-902.0	Sphere 5 G20 -1.4034 DIN 5401	2.000	ST