


20 Bottom part

Home and Garden \ Floor polisher \ FP 300 *AT \ Spare parts list FP 300 Hofer \ Bottom part



20 Bottom part

Home and Garden \ Floor polisher \ FP 300 *AT \ Spare parts list FP 300 Hofer \ Bottom part

KÄRCHER

POS	Article no.	Description	Quantity	Unit
1	4.195-172.0	Housing top part replacement FP 300/303	1	PC
2	6.612-978.0	Universal motor Ametek 0,4kW 220-240V, 5	1	PC
3	5.195-141.0	Retaining bracket /york	1	PC
4	4.195-159.0	Bolt complete replacement FP	2	PC
5	5.195-161.0	Pedal handle	1	PC
6	6.195-227.0	Locking ring pedal FP 303	1	PC
7	5.195-147.0	Motor bracket /motor plate	1	PC
8	5.195-149.0	Air circulation base body /air guide	1	PC
9	4.195-142.0	Blower extraction system complete	1	PC
10	6.959-070.0	Retainer gummed FP 222/FP 303	3	PC
11	6.959-072.0	Cover	3	PC
12	4.195-135.0	Brush holder right complete	1	PC
13	4.195-136.0	Brush holder left complete	1	PC
14	4.195-134.0	Brush holder front complete	1	PC
15	5.195-179.0	Pad holder	3	PC
16	2.863-198.0	Polishing pad stone FP 3pc.	1	PC
16	2.863-193.0	Polishing pad hard floor FP 3St.	1	PC
16	2.863-197.0	Polishing pad floor sealed FP 3pc.	1	PC
16	2.863-196.0	Polishing pad hard floor waxed FP 3St.	1	PC
18	4.195-161.0	Wheel set replacement FP	2	PC
19	4.195-156.0	Housing bottom part complete FP 303	1	PC
20	7.303-098.0	Screw 5x20 -10.9-R2R (K-In6Rd)	6	PC
21	6.195-223.0	Washer FP 303	3	PC
22	7.311-003.0	Hexagon nut M6 -8-A2E ISO 4032	3	PC
23	6.630-431.0	Switch	1	PC
24	5.195-261.0	Covering cap handhold opening /connectio	1	PC
25	4.195-166.0	Set spring replacement FP	1	PC
26	6.195-221.0	Spring pedal FP 303	1	PC
27	6.649-615.0	Cable with capacitor FP 303	1	PC
28	7.777-999.0	Stockpiling discontinued	1	PC