

Operating Instructions

Before first use of the unit read these operating instructions and act in accordance with them













Contents

General information	5
Safety instructions	5
Description of the Appliance	6
Preparing the Appliance	6
Start up	6
Operation	7
Finish operation	7
Helpline	8

Please read and comply with these original instructions prior to the initial operation of your appliance and store them for later use or subsequent owners.

Proper use

The underbody cleaner can be used with all KÄRCHER consumer high pressure cleaners.

It is not suitable for commercial use.

 The underbody cleaner is suitable for cleaning underbodies of regular cars/ SUVs, caravan and campers.

Due to the minimum construction height of approx. 11 cm, the cleaning of lowerlying cars is only conditionally possible.

General information

Environmental protection

▲ Caution!

When working with the underbody cleaner, make sure that the wastewater generated is disposed of into the public sewer system and then on to a wastewater treatment plant.

The packaging material can be recycled. Please do not place the packaging into the ordinary refuse for disposal, but arrange for the proper recycling.

Old appliances contain valuable materials that can be recycled. Please arrange for the proper recycling of old appliances. Please dispose your old appliances using appropriate collection systems.

Notes about the ingredients (REACH)

You will find current information about the ingredients at:

www.kaercher.com/REACH

Warranty

The warranty terms published by the relevant sales company are applicable in each country. We will repair potential failures of your appliance within the warranty period free of charge, provided that such failure is caused by faulty material or defects in manufacturing. In the event of a warranty claim please contact your dealer or the nearest authorized Customer Service centre. Please submit the proof of purchase.

Spare parts

Use only original KÄRCHER spare parts. You will find a list of spare parts at the end of these operating instructions.

Safety instructions

This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities.

The appliance must not be operated by children or persons who have not been instructed accordingly.

Children should be supervised to prevent them from playing with the appliance.

- Keep persons and objects out of the cleaning area while cleaning.
- Please observe the national and local regulations for car cleaning.
- Do not use directly after use of vehicle allow engine to cool first.
- Please observe the safety instructions of your high-pressure cleaner.
- Maximum water temperature 60°C (please observe the instructions of your high-pressure cleaner).
- Only use care products manufactured by KÄRCHER. The use of other detergents or chemicals may compromise the safety of the appliance.

Description of the Appliance

In the event of missing accessories or any transport damage, please contact your dealer.

Illustrations on fold-out page! Illustration



- 1 Care product nozzle
- 2 Care product container
- 3 Steering roller
- 4 Recessed grip
- 5 Protective grid for cleaning head
- 6 2 x high pressure nozzle, yellow
- 7 2 x high pressure nozzle, black
- 8 2 x high pressure nozzle, orange (already installed)
- 9 Cleaning head
- 10 Joint for height adjustment
- 11 Locking nut
- 12 Spray lance connection
- 13 Spray lances
- 14 Holder with spray lances
- 15 Rear support
- 16 Car wash shampoo (250 ml)
- 17 Underbody wax (250 ml)

Preparing the Appliance

Installing the nozzles

Select the nozzles to match the high pressure cleaner used.

K 2: Use yellow high pressure nozzles

K 3, K 4, K 5: Use black high-pressure nozzles

K 6, K 7: Use orange high pressure nozzles (already installed)

Illustration 2

→ Remove the protective grid from the cleaning head.

Illustration 3

- → Remove the clamp for the nozzle mount.
- ➔ Pull out the unneeded high pressure nozzle.

- Select the high pressure nozzle needed to match the high pressure cleaner used and press them in.
- ➔ Insert the clamp and secure the high pressure nozzle.
- ➔ Insert the protective grid and secure with clamps.

Assembling the underbody cleaner

Illustration 4

➔ Pull the two outer spray lances off of the intake; these will be needed later.

Illustration 5

- → Completely turn back the fastening nut on the connection of the cleaning head guide.
- ➔ Press the spray lance onto the connection; rotate all the way to the stop by 90°.
- ➔ Tighten the fastening nut and secure the connection.

Illustration 6

Press the rear support onto the spray lance; rotate all the way to the stop by 90°. Fasten with a fastening nut.

Illustration 7

➔ Press both spray lances onto the the rear support; rotate all the way to the stop by 90°. Fasten with fastening nuts.

Now, the underbody cleaner is ready to be used and connected to a KÄRCHER high pressure cleaner.

Note: The underbody cleaning should be performed prior to general car cleaning processes.

Start up

- Operate the high pressure cleaner as instructed in the operating instructions.
 Illustration 8
- ➔ Press the hand spray gun of the high pressure cleaner onto the spray lances; rotate all the way to the stop by 90°. Fasten with a fastening nut.

Operation

Note: Please read and observe the safety instructions prior to use!

Apply car wash shampoo

Apply the car wash shampoo with the care product nozzle under the body of the vecicle before starting the undercarriage wash.

- → Use the care product nozzle instead of the cleaning head.
- ➔ Fill in 0,2 liter car wash shampoo into the tank and apply.

Underbody claening

→ Turn on the high-pressure cleaner.
Illustration

Adjust the height of the cleaning head:

➔ Hold the cleaning head by the handle recess and set it to the desired height by pulling and pushing.

Illustration 10

- → Slide the underbody cleaner under the body of the vehicle.
- ➔ Unlock the lever on the hand spray gun (see high pressure cleaner operating instructions).
- ➔ Press the lever on the hand spray gun and begin cleaning (see high pressure cleaner operating instructions).

Note: The underbody cleaner with its articulating guide rollers can be moved effortlessly under the vehicle. If it gets stuck, please do not use excessive force.

Underbody care

You can apply care products after the underbody wash with the care product nozzle to preserve the vehicle.

Please observe the instructions on the care product bottle.

Illustration 11

- ➔ Use the care product nozzle instead of the cleaning head.
- → Fill 0.2 litres of care product into the care product container. Completely use up the container contents for the underbody care; do not pour the care product back into the bottle.
- ➔ For procedure see "Underbody cleaning".

Finish operation

After concluding the cleaning process, clean the care product nozzle, the cleaning head and the underbody cleaner:

➔ Remove the hand spray gun from the spray lance.

Illustration 12

- Press the lever on the hand spray gun and clean the underbody cleaner with a gentle water jet.
- ➔ After cleaning, switch off the high pressure cleaner.
- ➔ Unscrew the empty care product container from the care product nozzle.
- Clean the care product nozzle and the care product container under running water until all care product residue has been remvoed.

Storage

For space-saving - it is possible to store the underbody cleaner hanging up.

→ Clip both spray lances into their holders. Illustration **13**

➔ Hook the underbody cleaner onto the wall or into a KÄRCHER organiser (special accessory, order no. 2.641-630.0).

Helpline

KÄRCHER UK Limited operates a helpline allowing customers to discuss any problems experienced with our products. The helpline operates during normal business hours and may be busy at peak periods. If you have difficulty getting through we would ask that you try to contact us again later in the day.

The helpline number is 01295 752200, open from 8.30 am to 5.00 pm Monday to Friday.

It helps us if you have the model number and data plate details to hand before making your call so that we can assist you with your query more effectively.

Alternatively you may write to us at the address below:

KÄRCHER UK Ltd Kärcher House Beaumont Road Banbury Oxon, OX16 1TB

or E-mail us: info@karcher.co.uk



Α

Alfred Kärcher Ges.m.b.H. Lichtblaustraße 7 1220 Wien **7** (01) 250 600

AUS

Kärcher Pty. Ltd. 40 Koornang Road Scoresby VIC 3179 ☎ (03) 9765 - 2300

B / LUX

Kärcher N.V. Industrieweg 12 2320 Hoogstraten B: 0900 10027 LUX: 0032 900 10027

BR

Kärcher Indústria e Comércio Ltda. Av. Prof. Benedicto Montenegro 419 CEP 13.140-000 - Paulínia - SP 2000 176 111

CDN

Kärcher Canada Inc. 6975 Creditview Road Unit #2 Mississauga, Ontario L5N 8E9 **1**-800-465-4980

СН

Kärcher AG Industriestraße 16 8108 Dällikon 0844 850 863

cz

Kärcher spol s r.o. Modletice č.p. 141 251 01 Říčany u Prahy 20323 606 014

D

Alfred Kärcher GmbH & Co. KG Service-Center Gissigheim Im Gewerbegebiet 2 97953 Königheim-Gissigheim **7** (07195) 903 2065

DK

Kärcher Rengøringssystemer A/S Gejlhavegård 5 6000 Kolding 70 206 667

E

Kärcher S.A. Pol. Industrial Font del Radium Calle Doctor Trueta 6-7 08400 Granollers (Barcelona) **7** 902 170 068

F

Kärcher S.A.S. 5 Avenue des Coquelicots Z.A. des Petits Carreaux 94865 Bonneuil-sur-Marne **7** (01) 43 996 770

FIN Kärcher OY Yrittäjäntie 17 01800 Klaukkala 20 0207 413 600

GB

GR

Kärcher Cleaning Systems A.E. 31-33, Nikitara str. & Konstantinoupoleos str. 13671 Acharnes 210 - 2316 153

н

Kärcher Hungária Kft Tormásrét ut 2. 2051 Biatorbágy 2003) 530 640

ΗK

Kärcher Limited Unit 10, 17/F. APEC Plaza 49 Hoi Yuen Road Kwun Tong, Kowloon **a** (02) 357-5863

Kärcher S.p.A. Via A.Vespucci 19 21013 Gallarate (VA) **2** 848 - 99 88 77

IRL

KOR

Karcher (Korea) Co. Ltd. 162 Gukhoe-daero (872-2 Sinjeong-Dong) Seoul, Korea 02-322-6588. A/S. 1544-6577

MAL

Karcher Cleaning Systems Sdn. Bhd. No. 8, Jalan Serindit 2 Bandar Puchong Jaya 47100 Puchong, Selangor (03) 5882 1148

MEX

Karcher México, SA de CV Av. Gustavo Baz No. 29-C Col. Naucalpan Centro Naucalpan, Edo. de México C.P. 53000 México **7** 01 800 024 13 13

N Kärcher AS Stanseveien 31 0976 Oslo 24 17 77 00

NL

Kärcher BV Postbus 474 4870 AL Etten-Leur 2000-33 444 33

NZ

Karcher Limited 12 Ron Driver Place East Tamaki, Auckland **T** (09) 274-4603

Ρ

NEOPARTS II - Equipamentos, S.A. Av. Infante D. Henrique, Lote 35 1800-218 Lisboa 218558300

PL

Kärcher Sp. z o.o. UI. Stawowa 140 31-346 Kraków (012) 6397-222

PRC

Kärcher Cleaning Systems Co., Ltd. Part B, Building 30, No. 390 Ai Du Road Shanghai Waigaoquiao 200131 (021) 5046-3579

RO

Karcher Romania s.r.l. Sos. Odaii Nr. 439 013606 București 20 0372709001

RUS

ООО «Керхер», ул. Электрозаводская, д.27, стр.2, 107023 Москва Ф (495) 228 39 45

s

Kärcher AB Tagenevägen 31 42502 Hisings-Kärra **T** (031)577-300

SGP

Karcher Asia Pacific Pte. Ltd. 5 Toh Guan Road East #01-00 Freight Links Express Distripark Singapore 608831 **26** 6897-1811

SK

TR

Kärcher Servis Ticaret A.S. 9 Eylül Mahallesi 307 Sokak No. 6 Gaziemir / Izmir 7 (0232) 252-0708

TWN

Karcher Limited 5F/6. No.7 Wu-Chuan 1st Rd Wu-Ku Industrial Zone Taipei County **7** (02) 2299-9626

UA

Kärcher Ukraine Kilzeva doroga, 9 03191, Kyiv **2** (044) 594 75 75

UAE

Karcher FZE Jebel Ali Free Zone RA 8, XB 1, Jebel Ali, Dubai **T** (04) 8836-776

USA

Alfred Karcher, Inc 2170 Satellite Blvd Suite 350 Duluth, GA 30097 678-935-4545; 877-527-2437

ZA

Kärcher (Pty.) Limited 144 Kuschke Street Meadowdale Edenvale 1614 **T** (011) 574-5360



www.karcher.com