




K6414631  
DS6 / DS5500



#### DE

Filter prüfen!

Bei Nachlassen der Saugkraft oder bei Beschädigung Filter erneuern.

#### EN

Check filter!

Renew the filter if the suction force lessens or in case of damage.

#### FR

Vérifier le filtre !

Remplacer le filtre en cas de diminution de la puissance d'aspiration ou en cas d'endommagement.

#### ES

¡Comprobar el filtro!

Cambiar el filtro si disminuye la potencia de aspiración o está dañado.

#### IT




Verificare il filtro!

Rinnovare il filtro nel caso la forza di aspirazione diminuisca o in caso di danneggiamento.

#### RU

Проверить фильтр!

При ослаблении силы всасывания или при наличии повреждения заменить фильтр.

**DE**

Bei Filterwechsel Auflageflächen säubern.

**EN**

Clean contact surface upon filter change.

**FR**

Lors du remplacement du filtre,  
nettoyer les surfaces d'appui.

**ES**

Limpiar las superficies de apoyo al  
cambiar el filtro.

**IT**

Pulire le superfici d'appoggio al  
cambio del filtro.

**RU**

При смене фильтра очистить  
рабочую поверхность.