


20 Basic unit FC7

Home and Garden \ Hard surfaces cleaner \ FC 7 Cordless *EU \ Basic unit FC7



20 Basic unit FC7

Home and Garden \ Hard surfaces cleaner \ FC 7 Cordless *EU \ Basic unit FC7

KÄRCHER

POS	Article no.	Description	Quantity	Unit
1		Battery Pack replacement FC7 Samsung	1	PC
12		Clean water tank complete FC 7	1	PC
10	4.055-110.0	Filter complete for replacement	1	PC
15	4.101-259.0	Adapter cable handhold Molex FC7	1	PC
2	5.055-597.0	Connector	1	PC
3	5.055-598.3	Cap connector for replacement	1	PC
6	5.055-599.3	Cover rear cordless	1	PC
7	5.055-600.3	Bracket	1	PC
4	5.055-601.0	Strain relief	1	PC
8	5.055-602.3	Retainer with pins	1	PC
	Item text1: replaced by 9.013-703.3			
5	5.055-634.3	Profile aluminium for replacement FC 7	1	PC
11	6.303-557.0	Screw 3x12 Kombitorx T8	6	PC
9	6.362-376.0	O-Ring seal 24,0 X 1,5	1	PC
1	9.013-132.3	Battery Pack replacement FC7 EVE	1	PC
	Item text1: successor of 9.013-772.3			
8	9.013-703.3	System fresh water replacement	1	PC
	Item text1: successor of 5.055-602.3			
1	9.013-772.3	Electronics for replacement EVE pack FC7	1	PC
	Item text1: replaced by 9.013-132.3			