

Spare parts list


(5.958-793.0) Spare parts list RM-SPRAYER

Table of contents

9 Spare parts list RM-SPRAYER (5.958-793.0)	3
10 Individual parts	4

9 Spare parts list RM-SPRAYER (5.958-793.0)

POS	Description	Quantity	Unit
10	Individual parts	1.000	ST



10 Individual parts

POS	Article no.	Description	Quantity	Unit	Foot note text
5	6.955-041.0	Hose complete 1,7M	1.000	ST	
1	6.955-043.0	Jet pipe complete	1.000	ST	SPECIAL ACCESSORIES
6	6.955-040.0	Pressure control valve	1.000	ST	
3	6.955-037.0	Pump with handhold complete	1.000	ST	
4	6.955-038.0	Set of gaskets	1.000	ST	
2	6.955-042.0	Spray gun	1.000	ST	
8	6.955-044.0	Spraying nozzle complete	1.000	ST	
7	7.777-999.0	Stockpiling discontinued	1.000	ST	
10	6.955-046.0	Strainer	1.000	ST	
9	6.955-045.0	Tube spraying lance	1.000	ST	STANDARD