

## **Spare parts list**

(2.645-214.0) SensoTimer ST6 Duo eco!ogic

## Table of contents

---

1 SensoTimer ST6 Duo eco!ogic (2.645-214.0)	3
Spare parts list ST 6 duo (5.973-031.0)	4
10 Individual parts	5

1 SensoTimer ST6 Duo ecologic (2.645-214.0)

---



POS	Article no.	Description	Quantity	Unit
0	5.973-031.0	Spare parts list ST 6 duo	1	PC

---

Spare parts list ST 6 duo (5.973-031.0)

---

POS	Description	Quantity	Unit
10	Individual parts	1	PC



## 10 Individual parts

---

<b>POS</b>	<b>Article no.</b>	<b>Description</b>	<b>Quantity</b>	<b>Unit</b>
9	5.645-806.0	Cap	2	PC
6	6.465-031.0	Connection 3/4	2	PC
12	5.645-807.0	Cover sensor	2	PC
5	6.645-514.0	Filter for G1	1	PC
3	4.645-483.0	Multi Valve	1	PC
2	6.645-673.0	O-Ring seal 70x2,5	1	PC
1	4.645-480.0	Operating unit	1	PC
10	6.303-557.0	Screw 3x12 Kombitorx T8	6	PC
8	4.645-499.0	Sensor	2	PC
11	2.645-242.0	Sensor Pad 2er Set	2	PC
4	2.645-007.0	Tap adaptor with reducer G1	1	PC