

K 5500 New Unit Information

International Service Information Dec. 5th, 2000

K 5500 1.195-... mannut


5.906-129




New Unit Information

International Service Information Dec. 5th, 2000

Equipment Features





Rearview

- 1 Unit switch
- 2 Pushbutton, cable retraction
- 3 Floor tool
- 4 Telescopic suction tube
- 5 Accessory holder
- 6 Upholsterytool
- 7 Handle with adjustable false air opening
- 8 Suction hose
- 9 Furniture tool

- 10 Crevice tool
- 11 Carrying handle
- 12 Flat pleated filter
- 13 Water tank cover
- 14 Deflection plate
- 15 Watertank
- 16 Antifoam additive
- 17 Filter lid (of HEPA exhaust air filter)
- 18 Wheel(2x)



New Unit Information

International Service Information Dec. 5th, 2000

Technical Features

- This water filtration vacuum cleaner is suitable for allergy sufferers. The drawn in air is cleaned by a filter system containing 3 filters. No filter bags are necessary.
- Transparent water tank
- 2 big wheels, 2 swivel castors

Filter and suction system

– Waterfilter:

The drawn in air is cleaned in the water bath (2 litres) of the water tank, separating power of 98.3%. It is necessary to add an antifoam additive to avoid foaming in the water tank.

- Flat pleated filter (washable):
 The drawn in air is filtered after the water bath.
- HEPA exhaust air filter (HEPA = High Efficiency Particulate Air): The drawn in air and also cooling air of the

suction motor can be filtered from all particles up to 99.99% (> $0.3 \ \mu m$).

- Wet-vacuuming possible:
 When the water tank contains 2 litres water, further 0.5 litre fluids can be vacuumed.
 2.5 litres max. can be drawn in, when the water tank is empty.
- Suction hose connection(DN 35)
- Suction power regulation by means of adjustable false air opening at handle

Drive system

- Single-phase universal motor
- Bypass suction motor
- Incased in sound absorbing hood

Electrical system


- Protection class II
- Unit switch
- Automatic cable retraction



New Unit Information

International Service Information Dec. 5th, 2000

Unit Functions




- 1 Air inlet
- 2 Air discharge
- 3 HEPA exhaust air filter (for drawn in air and cooling air of the suction motor)
- 4 Flat pleated filter
- 5 Water filter



New Unit Information


International Service Information Dec. 5th, 2000

Service Work: Disassembly




1. Removing wheel


Pull out wheel by using a disassembly sleeve Carefully press clips to remove cable guide. (see special tools).



2. Removing container latch Remove container latch. Remove HEPA exhaust air filter.



3. Removing cable guide




4. Removing unit screws Remove all 6 screws with torx-screwdriver TX 20 (see special tools).




New Unit Information

International Service Information Dec. 5th, 2000

Service Work: Disassembly




5. Unit cover removed



7. Removing suction motor cover

The suction motor cover is mounted on the base plate by 4 screws.




6. Removing unit switch



New Unit Information


International Service Information Dec. 5th, 2000

Service Work: Assembly




1. Base plate

Insert sponge rubber seal (1) and rubber retainer (2) of the suction motor correctly when assembling.



^{2.} Lock spring

Install lock spring correctly when assembling. Otherwise the water tank cannot be enganged.



3. Reinstall suction motor cover

Sprinkle some soap water on suction motor seals. Pay attention to the position of the suction motor and lower part of the cable guide. Carefully install suction motor cover and fasten with 4 screws. Do not clamp the cables of the suction motor.

4. Finishing assembly (analogous to disassemby):


- Reinstall the unit switch
- Remount upper part of the unit housing (6 screws)
- Carefully engage clips of the cable guide
- Insert the container latch
- Mount the wheels



New Unit Information

International Service Information Dec. 5th, 2000


Service Work: Maintenance



Clean the water tank, filter lid and deflection plate after each vacuuming operation.

Rinse and completely dry flat pleaded filter every two weeks when vacuuming regularly.

Flat pleaded filter



HEPA exhaust air filter

Replace HEPA exhaust filter after 15 months operation. If it is damaged or extremely dirty, replace sooner.

Note:

Do not rinse the HEPA exhaust filter, only clean dry (lightly beat the dirt out of it).



New Unit Information

International Service Information Dec. 5th, 2000

Troubleshooting

Problem	Solution		
Suction motor does not run.	 Check fuse, plug socket and voltage supply. Check cable, cable drum with mains plug. Check / replace unit switch. Check / replace suction motor. 		
Poor vacuuming results	 Check suction nozzle, suction tube, handle, suction hose for blockage and eliminate it. Check / close false air opening of handle. Check suction system (suction hose connection, filter seat, sponge rubber seal at base plate, rubber retainer of the suction motor) for leakage and eliminate it. Water tank is not completely engaged, check opening mechanism with lock spring. Check water level in water tank, pay attention to MIN./ MAX. mark at tank. Check flat pleated filter: a) Filter is clogged: clean it. b) Filter is wet and clogged: clean and dry. c) Filter is worn-out: replace it. d) Filter is not correctly positioned: install it again. Check HEPA exhaust air filter: a) Filter is wet and clogged: replace it. c) Filter is wet and clogged: replace it. d) Filter is not correctly positioned: install it again. 		
Heavy foaming in water tank	 No antifoam additive Replace water bath (2 litres) and add one cowl of antifoam additive to water tank. 		



New Unit Information

International Service Information Dec. 5th, 2000

Specifications

unit	specifica- tions	circuit diagram	operating instructions	maintenance booklet	spare parts list
K 5500 EU 230/240 V, 50/60 Hz	1.195-101	0.088-268	5.959-297	-	5.958-658
K 5500 CH 230/240 V, 50/60 Hz	1.195-102	0.088-268	5.959-297	-	5.958-658
K 5500 AUS 230/240 V, 50/60 Hz	1.195-103	0.088-268	5.959-297	-	5.958-658
K 5500 GB 230/240 V, 50/60 Hz	1.195-104	0.088-268	5.959-297	-	5.958-658

The technical specification sheets and the circuit diagram are on the next edition of the spare parts CD-ROM (DISIS) and in the Intranet .

Technical specification sheets: folder "Central / Service Info Int'l / Technical Specifications" Circuit diagram: folder "Central / Service Info Int'l / Circuit Diagram"

Further operating instructions and the spare parts lists can be ordered with the corresponding part number from our Spare Parts Dept.

Special Tools

Sleeve (disassembly of the wheels)	. 2.901-039
Screwdriver TX 20	. 6.815-166
Adapter 3/8"	. 6.815-139
Extension	. 6.815-043

Assembly Torque Ratings

No details required.